

# SAMSUNG

# FULL MANUAL

---

## HW-B550

Imagine the possibilities

Thank you for purchasing this Samsung product.









To receive more complete service, please register  
your product at [www.samsung.com/register](http://www.samsung.com/register)

# SAFETY INFORMATION

## SAFETY WARNINGS

TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE THE COVER (OR BACK). NO USER-SERVICEABLE PARTS ARE INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.

Refer to the table below for an explanation of symbols which may be on your Samsung product.

	<div>CAUTION</div> <div>RISK OF ELECTRIC SHOCK.</div> <div>DO NOT OPEN.</div>	
	This symbol indicates that high voltage is present inside. It is dangerous to make any kind of contact with any internal part of this product.	
	This symbol indicates that this product has included important literature concerning operation and maintenance.	
	Class II product : This symbol indicates that it does not require a safety connection to electrical earth (ground). If this symbol is not present on a product with a power cord, the product MUST have a reliable connection to protective earth (ground).	
	AC voltage : This symbol indicates that the rated voltage marked with the symbol is AC voltage.	
	DC voltage : This symbol indicates that the rated voltage marked with the symbol is DC voltage.	
	Caution, Consult instructions for use : This symbol instructs the user to consult the user manual for further safety related information.	

## WARNING

- To reduce the risk of fire or electric shock, do not expose this appliance to rain or moisture.

## CAUTION

- TO PREVENT ELECTRIC SHOCK, MATCH WIDE BLADE OF PLUG TO WIDE SLOT, FULLY INSERT.
- This apparatus shall always be connected to a AC outlet with a protective grounding connection.
- To disconnect the apparatus from the mains, the plug must be pulled out from the mains socket, therefore the mains plug shall be readily operable.
- Do not expose this apparatus to dripping or splashing. Do not put objects filled with liquids, such as vases on the apparatus.
- To turn this apparatus off completely, you must pull the power plug out of the wall socket. Consequently, the power plug must be easily and readily accessible at all times.

# PRECAUTIONS











1. Ensure that the AC power supply in your house complies with the power requirements listed on the identification sticker located on the bottom of your product. Install your product horizontally, on a suitable base (furniture), with enough space around it for ventilation (7~10 cm). Make sure the ventilation slots are not covered. Do not place the unit on amplifiers or other equipment which may become hot. This unit is designed for continuous use. To fully turn off the unit, disconnect the AC plug from the wall outlet. Unplug the unit if you intend to leave it unused for a long period of time.
2. During thunderstorms, disconnect the AC plug from the wall outlet. Voltage peaks due to lightning could damage the unit.
3. Do not expose the unit to direct sunlight or other heat sources. This could lead to overheating and cause the unit to malfunction.
4. Protect the product from moisture (i.e. vases), and excess heat (e.g. a fireplace) or equipment creating strong magnetic or electric fields. Unplug the power cable from the AC wall socket if the unit malfunctions. Your product is not intended for industrial use. It is for personal use only. Condensation may occur if your product has been stored in cold temperatures. If transporting the unit during the winter, wait approximately 2 hours until the unit has reached room temperature before using.
5. The battery used with this product contains chemicals that are harmful to the environment. Do not dispose of the battery in the general household trash. Do not expose the battery to excess heat, direct sunlight, or fire. Do not short circuit, disassemble, or overheat the battery.  
**CAUTION :** Danger of explosion if the battery is replaced incorrectly. Replace only with the same or equivalent type.

# CONTENTS

<b>01</b>	<b>Checking the Components</b>	<b>6</b>
<b>02</b>	<b>Product Overview</b>	<b>7</b>
	Front Panel / Top Panel of the Soundbar	7
	Bottom Panel of the Soundbar	8
<b>03</b>	<b>Using the Remote Control</b>	<b>9</b>
	Inserting Batteries before using the Remote Control (AAA batteries X 2)	9
	How to Use the Remote Control	9
	Using the Hidden Buttons (Buttons with more than one function)	13
	Output specifications for the different sound effect modes	13
	Adjusting the Soundbar volume with a TV remote control	14
<b>04</b>	<b>Connecting the Soundbar</b>	<b>15</b>
	Connecting Electrical Power	15
	Connecting the Soundbar to the Subwoofer	16
	Connecting the Samsung Wireless Rear Kit to your Soundbar	18
<b>05</b>	<b>Using a wired connection to the TV</b>	<b>19</b>
	Method 1. Connecting a TV using an HDMI Cable	19
	Method 2. Connecting using an Optical Cable	21
<b>06</b>	<b>Using a wireless connection to the TV</b>	<b>22</b>
	Connecting a TV via Bluetooth	22

<b>07</b>	<b>Connecting an External Device</b>	<b>24</b>
	Method 1. Connecting using an HDMI Cable	24
	Method 2. Connecting using an Optical Cable	25
<b>08</b>	<b>Connecting a USB Storage Device</b>	<b>26</b>
<b>09</b>	<b>Connecting a Mobile Device</b>	<b>27</b>
	Connecting via Bluetooth	27
<b>10</b>	<b>Installing the Wall Mount</b>	<b>31</b>
	Installation Precautions	31
	Wallmount Components	31
<b>11</b>	<b>Software Update</b>	<b>33</b>
	How to check the Firmware version	33
	Update Procedure	34
	If UPDATE is not displayed	34
<b>12</b>	<b>Troubleshooting</b>	<b>35</b>
<b>13</b>	<b>Licence</b>	<b>37</b>
<b>14</b>	<b>Open Source Licence Notice</b>	<b>38</b>
<b>15</b>	<b>Important Notes About Service</b>	<b>38</b>
<b>16</b>	<b>Specifications and Guide</b>	<b>39</b>
	Specifications	39


# 01 CHECKING THE COMPONENTS

			
Soundbar Main Unit	Subwoofer	Remote Control / Batteries	
			
Power Cord (Subwoofer, Soundbar)	AC/DC Adapter (Soundbar)	HDMI Cable	
			
Wall Mount Guide	Holder-Screw	Screw	Bracket-Wall Mount

- For more information about the power supply and power consumption, refer to the label attached to the product. (Label: Bottom of the Soundbar Main Unit)
- To purchase additional components or optional cables, contact a Samsung Service Centre or Samsung Customer Care.
- Depending on the region, the appearance of the AC plug may differ from the plug displayed above, or it may be supplied integrated with the AC/DC adapter.
- The appearance of the accessories may differ slightly from the illustrations above.
- Design and specifications are subject to change without prior notice.

# 02 PRODUCT OVERVIEW


## Front Panel / Top Panel of the Soundbar



1	<b>Display</b> Displays the product's status and current mode.												
2	<b>⏻ (Power) Button</b> Turns the power on and off. <ul style="list-style-type: none"><li>• <b>Auto Power Down Function</b> The unit turns off automatically in the following situations:<ul style="list-style-type: none"><li>– In <b>D.IN / HDMI / BT / USB</b> Mode : If there is no audio signal for 20 minutes.</li></ul></li></ul>												
3	<b>— + (Volume) Button</b> Adjusts the volume. <ul style="list-style-type: none"><li>• When adjusted, the volume level appears on the Soundbar's front display.</li></ul>												
4	<b>➡ (Source) Button</b> Selects the source input mode. <table><tr><th>Input mode</th><th>Display</th></tr><tr><td>Optical Digital input</td><td>D.IN</td></tr><tr><td>ARC (HDMI OUT) input</td><td>D.IN → TV ARC (Auto conversion)</td></tr><tr><td>HDMI input</td><td>HDMI</td></tr><tr><td>BLUETOOTH mode</td><td>BT</td></tr><tr><td>USB mode</td><td>USB</td></tr></table> <ul style="list-style-type: none"><li>• To turn on "<b>BT PAIRING</b>" mode, change the source to "<b>BT</b>" mode, and then press and hold the <b>➡ (Source)</b> button for more than 5 seconds.</li></ul>	Input mode	Display	Optical Digital input	D.IN	ARC (HDMI OUT) input	D.IN → TV ARC (Auto conversion)	HDMI input	HDMI	BLUETOOTH mode	BT	USB mode	USB
Input mode	Display												
Optical Digital input	D.IN												
ARC (HDMI OUT) input	D.IN → TV ARC (Auto conversion)												
HDMI input	HDMI												
BLUETOOTH mode	BT												
USB mode	USB												

- When you plug in the AC cord, the power button will begin working in 4 to 6 seconds.
- When you turn on this unit, there will be a 4 to 5 second delay before it produces sound.
- If you want to enjoy sound only from the Soundbar, you must turn off the TV's speakers in the Audio Setup menu of your TV. Refer to the owner's manual supplied with your TV.

# Bottom Panel of the Soundbar



1	<b>DIGITAL AUDIO IN (OPTICAL)</b> Connect to the digital (optical) output of an external device.
2	<b>USB (5V 0.5A)</b> Connect a USB device here to play music files stored on the USB device through the Soundbar.
3	<b>HDMI IN</b> Inputs digital video and audio signals simultaneously using an HDMI cable. Connect to the HDMI output of an external device.
4	<b>HDMI TO TV (ARC)</b> Connect to the HDMI (ARC) port on a TV.
5	<b>DC 24V (Power Supply In)</b> Connect the AC/DC power adapter.


- When disconnecting the power cable of the AC/DC power adapter from a wall outlet, pull the plug. Do not pull the cable.
- Do not connect this unit or other components to an AC outlet until all connections between components are complete.

# 03 USING THE REMOTE CONTROL


## Inserting Batteries before using the Remote Control (AAA batteries X 2)








Slide the back cover in the direction of the arrow until it is completely removed.








Insert 2 AAA batteries (1.5V) oriented so that their polarity is correct. Slide the back cover back into position.










## How to Use the Remote Control





1	 Power	Turns the Soundbar on and off.
2	 Source	Press to select a source connected to the Soundbar.
3	 Mute	Press the  ( <b>Mute</b> ) button to mute the sound. Press it again to unmute the sound.
4	 Volume	<div></div> <p>Push the button up or down to adjust the volume.</p> <ul style="list-style-type: none"><li>• <b>Mute</b> Press the <b>Volume</b> button in to mute the sound. Press it in again to unmute the sound.</li></ul>

5	 CH LEVEL	<p>By pressing the button, you can adjust the volume of the each speaker.</p> <ul style="list-style-type: none"> <li>Press the button to select <b>VIRTUAL CENTER LEVEL</b> and then adjust the volume between -6~+6 by using the <b>Up/Down</b> buttons.</li> <li>If the Rear Speakers (sold separately) are connected, the setting <b>REAR LEVEL</b> is supported. To adjust the volume of the <b>REAR LEVEL</b> between -6 to +6 by using the <b>Up/Down</b> buttons.</li> </ul>
6	 Sound Control	<p>By pressing the button, you can set the audio function. The desired settings can be adjusted using the <b>Up/Down</b> buttons.</p> <p><b>AUDIO SYNC → NIGHT MODE ON/OFF → VOICE ENHANCE ON/OFF</b></p> <ul style="list-style-type: none"> <li><b>AUDIO SYNC</b> If the video on the TV and audio from the Soundbar are not synchronised, press the  (<b>Sound Control</b>) button to select <b>AUDIO SYNC</b> and then set the audio delay between 0~300 milliseconds by using the <b>Up/Down</b> buttons. (Not available in “<b>USB</b>” or “<b>BT</b>” mode.)</li> <li><b>NIGHT MODE ON/OFF</b> This mode is optimized for nighttime viewing with the settings adjusted to bring the volume down but keep the dialog clear.</li> <li><b>VOICE ENHANCE ON/OFF</b> This mode is makes it easier to hear spoken dialog in movies and TV. <ul style="list-style-type: none"> <li>The <b>NIGHT MODE</b>, and <b>VOICE ENHANCE</b> audio function can be turned <b>ON/OFF</b> by using the <b>Up/Down</b> buttons.</li> <li>Press and hold the  (<b>Sound Control</b>) button for about 5 seconds to adjust the sound for each frequency band. 150Hz, 300Hz, 600Hz, 1.2kHz, 2.5kHz, 5kHz, and 10kHz are selectable using the <b>Left/Right</b> buttons and each can be adjusted to a setting between -6 to +6 using the <b>Up/Down</b> buttons. (Make sure the Sound mode is set to “<b>STANDARD</b>”.)</li> </ul> </li> </ul>
7	 Bluetooth PAIR	<p>Switch the Soundbar to Bluetooth pairing mode.</p> <p>Press the  <b>PAIR</b> button and wait for the “<b>BT PAIRING</b>” screen to connect to a new Bluetooth device.</p>
8	 Play / Pause	<p>You can also play or pause music by pressing the button.</p>


<b>9</b>	 Up/Down/ Left/Right	 <p>Press the indicated areas to select Up/Down/Left/Right.</p> <p>Press Up/Down/Left/Right on the button to select or set functions.</p> <ul style="list-style-type: none"> <li>• <b>Repeat</b> To use the Repeat function in “<b>USB</b>” mode, press the <b>Up</b> button.</li> <li>• <b>Music Skip</b> Press the <b>Right</b> button to select the next music file. Press the <b>Left</b> button to select the previous music file.</li> <li>• <b>ID SET</b> Press and hold the <b>Up</b> button for 5 seconds to complete <b>ID SET</b> (when connecting to a wireless subwoofer or wireless rear speakers).</li> </ul>
<b>10</b>	 Info	<p>Press the button to display information about the current function. (See page 7.)</p>

<div>11</div>	<div>  </div> <div> SOUND MODE </div>	<p>By pressing the button, you can select the desired sound mode.</p> <p><b>SURROUND SOUND → BASS BOOST → GAME → ADAPTIVE → DTS VIRTUAL:X → STANDARD</b></p> <ul style="list-style-type: none"> <li>– <b>SURROUND SOUND</b> Provides a wider sound field than standard.</li> <li>– <b>BASS BOOST</b> Sound field mode with emphasis on bass sound.</li> <li>– <b>GAME</b> Provides stereoscopic sound to immerse you in the action while gaming.</li> <li>– <b>ADAPTIVE</b> Analyzes the content in real time and automatically provides an optimal sound field based on the characteristics of the content.</li> <li>– <b>DTS VIRTUAL:X</b> Immersive 3D sound from any content.</li> <li>– <b>STANDARD</b> Outputs the original sound.</li> <li>• <b>DRC (Dynamic Range Control)</b> Lets you apply dynamic range control to Dolby Digital tracks. Press and hold the <b>SOUND MODE</b> button for more than 5 seconds while the Soundbar is powered off to turn DRC (Dynamic Range Control) on or off. With the DRC turned on, loud sound is reduced. (The sound may be distorted.)</li> <li>• <b>Bluetooth Power</b> This feature automatically turns the Soundbar on when it receives a connection request from a previously connected TV or Bluetooth device. The setting is On by default. <ul style="list-style-type: none"> <li>– Press and hold the <b>SOUND MODE</b> button for more than 5 seconds to turn off the Bluetooth Power function.</li> </ul> </li> </ul>
<div>12</div>	<div>  </div> <div> WOOFER WOOFER (BASS) LEVEL </div>	<div>  </div> <p>Push the button up or down to adjust the level of the woofer (bass) to -12 or between -6 to +6. To set the woofer (bass) volume level to 0 (Default), press the button.</p>
<div>13</div>	<div>  </div> <div> TONE CONTROL </div>	<p>By pressing the button, you can adjust the volume of the treble or bass sound.</p> <ul style="list-style-type: none"> <li>• Press the button to select <b>TREBLE</b> or <b>BASS</b> and then adjust the volume between -6~+6 by using the <b>Up/Down</b> buttons.</li> </ul>

# Using the Hidden Buttons (Buttons with more than one function)

Hidden Button		Reference page
Remote Control Button	Function	
WOOFER (Up)	TV remote control On/Off (Standby)	page 14
Left	TV Auto connect On/Off (BT Ready)	page 23
Up	ID SET	page 11
 (Sound Control)	7 Band EQ	page 10
SOUND MODE	DRC ON/OFF (Standby)	page 12
	Bluetooth Power	page 12
 PAIR	Bluetooth Multi-connection On/Off (Standby)	page 30

## Output specifications for the different sound effect modes

Effect		Input	Output	
			Without Wireless Rear Speaker Kit	With Wireless Rear Speaker Kit
 SOUND MODE	SURROUND SOUND	2.0 ch	2.1 ch	4.1 ch
		5.1 ch	2.1 ch	4.1 ch
	BASS BOOST	2.0 ch	2.1 ch	4.1 ch
		5.1 ch	2.1 ch	4.1 ch
	GAME	2.0 ch	2.1 ch	4.1 ch
		5.1 ch	2.1 ch	4.1 ch
	ADAPTIVE	2.0 ch	2.1 ch	4.1 ch
		5.1 ch	2.1 ch	4.1 ch
	DTS VIRTUAL:X	2.0 ch	2.1 ch	4.1 ch
		5.1 ch	2.1 ch	4.1 ch
	STANDARD	2.0 ch	2.1 ch	2.1 ch
		5.1 ch	2.1 ch	2.1 ch







- The Samsung Wireless Rear Speaker Kit can be purchased separately. To purchase a Kit, contact the vendor you purchased the Soundbar from.

# Adjusting the Soundbar volume with a TV remote control

Adjust the Soundbar volume using the TV's remote control.

- This function can be used with IR remote controls only. Bluetooth remote controls (remote controls that require pairing) are not supported.
- Set the TV speaker to **External Speaker** to use this function.
- Manufacturers supporting this function:  
Samsung, VIZIO, LG, Sony, Sharp, PHILIPS, PANASONIC, TOSHIBA, Hisense, RCA

1. Turn Off the Soundbar.
2. Push up and hold the **WOOFER** button for 5 seconds.  
Each time you push the **WOOFER** button up and hold it for 5 seconds, the mode switches in the following order: “**OFF-TV REMOTE**” (Default mode), “**SAMSUNG-TV REMOTE**”, “**ALL-TV REMOTE**”.

Remote Control Button	Display	Status
	(Default mode) 	Disable the TV remote control.
		Enable a Samsung TV's IR remote control.
		Enable a third-party TV's IR remote control.

## 04 CONNECTING THE SOUNDBAR


### Connecting Electrical Power

Use the power components to connect the Subwoofer and Soundbar to an electrical outlet in the following order:

1. Connect the power cord to the Subwoofer.
2. Connect the power output cable to the power adapter, and then to the Soundbar.
3. Connect the power cord to a wall socket.

See the illustrations below.

- For more information about the required electrical power and power consumption, refer to the label attached to the product. (Label: Bottom of the Soundbar Main Unit)



- Make sure to rest the AC/DC Adapter flat on a table or the floor. If you place the AC/DC Adapter so that it is hanging with the AC cord input facing upwards, water or other foreign substances could enter the Adapter and cause the Adapter to malfunction.

# Connecting the Soundbar to the Subwoofer




When the subwoofer is connected, you can enjoy rich bass sound.

## Automatic connection between the Subwoofer and the Soundbar

When you turn the power on after connecting the power cables to the Soundbar and subwoofer, the subwoofer is automatically connected to the Soundbar.

- When auto pairing is complete, the blue indicators at the rear of the subwoofer turn on.

## LED Indicator Lights on the Rear of Subwoofer


LED	Status	Description	Resolution
	On	Successfully connected (normal operation)	-
	Blinking	Recovering the connection	Check if the power cable attached to the main Soundbar unit is connected properly or wait about 5 minutes. If blinking persists, try manually connecting the subwoofer. See page 17.
	On	Standby (with the Soundbar main unit turned off)	Check if the power cable attached to the main Soundbar unit is connected properly.
		Connection failed	Connect again. See the instructions for manual connection on page 17.
	Blinking	Malfunction	See the contact information for the Samsung Service Centre in this manual.

## Manually connecting the Subwoofer if automatic connection fails

### Before performing the manual connection procedure below:


- Check whether the power cables for the Soundbar and subwoofer are connected properly.
- Make sure that the Soundbar is turned on.

1. Press and hold **ID SET** on the rear of the subwoofer for at least 5 seconds.
  - The red indicator on the rear of the subwoofer turns off and the blue indicator blinks.




Rear of Subwoofer

2. Press and hold the **Up** button on the remote control for at least 5 seconds.
  - The **ID SET** message appears on the display of the Soundbar for a moment, and then it disappears.
  - The Soundbar will automatically power on when **ID SET** is complete.



3. Check if the LINK LED is solid blue (connection complete).



The LINK LED indicator stops blinking and glows a solid blue when a connection is established between the Soundbar and the Wireless Subwoofer.

## NOTES

- Do not connect the power cord of this product or your TV to a wall outlet until all connections between components are complete.
- Before moving or installing this product, be sure to turn off the power and disconnect the power cord.
- If the main unit is powered off, the wireless subwoofer will go into stand-by mode and the STANDBY LED on the rear of the sub-woofer will turn red after blinking blue several times.
- If you use a device that uses the same frequency (5.8GHz) as the Soundbar near the Soundbar, interference may cause some sound interruption.
- The maximum transmission distance of the main unit's wireless signal is about 10 m, but may vary depending on your operating environment. If a steel-concrete or metallic wall is between the main unit and the wireless subwoofer, the system may not operate at all because the wireless signal cannot penetrate metal.

## PRECAUTIONS

- Wireless receiving antennas are built into the wireless subwoofer. Keep the unit away from water and moisture.
- For optimal listening performance, make sure that the area around the wireless subwoofer and the Wireless Receiver Module (sold separately) is clear of any obstructions.

## Connecting the Samsung Wireless Rear Kit to your Soundbar

Expand to true wireless surround sound by connecting the Samsung Wireless Rear Speaker Kit (SWA-9100S or SWA-9200S sold separately) to your Soundbar.

For detailed information on connections, see the Samsung Wireless Rear Speaker Kit manual.

# 05 USING A WIRED CONNECTION TO THE TV


Hear TV sound from your Soundbar through wired or wireless connections.

- When the Soundbar is connected to selected Samsung TVs, the Soundbar can be controlled using the TV's remote control.
  - This feature is supported by 2017 and later Samsung Smart TVs that support Bluetooth when you connect the Soundbar to the TV using an optical cable.
  - This function also allows you to use the TV menu to adjust the sound field and various settings as well as the volume and mute.


## Method 1. Connecting a TV using an HDMI Cable

### ⚠ CAUTION

- When both the HDMI cable and optical cable are connected, the HDMI signal is received first.
- To connect the HDMI cable between the TV and Soundbar, be sure to connect the terminals marked ARC. Otherwise, the TV sound may not be output.
- The recommended cable is **High Speed HDMI Cable with Ethernet**.



1. With the Soundbar and TV turned on, connect the HDMI cable as shown in the figure.
2. "TV ARC" appears in the display window of the Soundbar main unit and the Soundbar plays TV sound.

- If TV sound is inaudible, press the  (**Source**) button on the remote control or on the top of the Soundbar to switch to “**D.IN**” mode. The screen displays “**D.IN**” and “**TV ARC**” in sequence, and TV sound is played.
- If “**TV ARC**” does not appear in the display window of the Soundbar main unit, confirm that the HDMI cable is connected to the correct port.
- Use the volume buttons on the TV’s remote control to change the volume on the Soundbar.


## NOTES


- HDMI is an interface that enables the digital transmission of video and audio data with just a single connector.
- If the TV provides an ARC port, connect the HDMI cable to the HDMI IN (ARC) port.
- We recommend you use a coreless HDMI cable if possible. If you use a cored HDMI cable, use one whose diameter is less than 14 mm.
- This function is not available if the HDMI cable does not support ARC.
- When the audio in a broadcast is encoded in Dolby Digital and the “Digital Output Audio Format” on your TV is set to PCM, we recommend that you change the setting to Dolby Digital. When the setting on the TV is changed, you will experience better sound quality. (The TV menu may use different words for Dolby Digital and PCM depending on the TV manufacturer.)

## Method 2. Connecting using an Optical Cable

### Pre-connection Checklist

- When both the HDMI cable and optical cable are connected, the HDMI signal is received first.
- When you use an optical cable and the terminals have covers, be sure to remove the covers.




1. Connect the **DIGITAL AUDIO IN (OPTICAL)** port on the Soundbar to the OPTICAL OUT port of the TV with a digital optical cable (not supplied).
2. Press the  (**Source**) button on the top panel or remote control, and then select the “**D.IN**” mode.

## 06 USING A WIRELESS CONNECTION TO THE TV

### Connecting a TV via Bluetooth

When a TV is connected using Bluetooth, you can hear stereo sound without the hassle of cabling.

- Only one TV can be connected at a time.



### The initial connection

1. Press the **PAIR** button on the remote control to enter the **"BT PAIRING"** mode.

(OR) a. Press the **(Source)** button on the top panel and then select **"BT"**.

**"BT"** changes to **"BT PAIRING"** in a few seconds automatically or changes to **"BT READY"** if there is a connect record.

- b. When **"BT READY"** appears, press and hold the **(Source)** button on the top panel of the Soundbar for more than 5 seconds to display **"BT PAIRING"**.

2. Select Bluetooth mode on the TV. (For more information, see the TV's manual.)

3. Select **"[AV] Soundbar B5-Series"** from the list on TV's screen.

An available Soundbar is indicated with **"Needs pairing"** or **"Paired"** on the TV's Bluetooth device list. To connect the TV to the Soundbar, select the message, and then establish a connection.

- When the TV is connected, **[TV Name] → "BT"** appears on the Soundbar's front display.

4. You can now hear TV sound from the Soundbar.


### If the device fails to connect

- If a previously connected Soundbar listing (e.g. **"[AV] Soundbar B5-Series"**) appears in the list, delete it.
- Then repeat steps 1 through 3.

### NOTE



- After you have connected the Soundbar to your TV the first time, use the **"BT READY"** mode to reconnect.

## Disconnecting the Soundbar from the TV

Press the  (**Source**) button on the top panel or on the remote control and switch to any mode but “**BT**”.

- Disconnecting takes time because the TV must receive a response from the Soundbar. (The time required may differ, depending on the TV model.)
- To cancel the automatic Bluetooth connection between the Soundbar and TV, press the **Left** button on the remote control for 5 seconds with the Soundbar in “**BT READY**” status. (Toggle On → Off)

## What is the difference between BT READY and BT PAIRING?

- **BT READY** : In this mode, you can search for previously connected TVs or connect a previously connected mobile device to the Soundbar.
- **BT PAIRING** : In this mode, you can connect a new device to the Soundbar. (Press the  **PAIR** button on the remote control or press and hold the  (**Source**) button on the top of the Soundbar for more than 5 seconds while the Soundbar is in “**BT**” mode.)


## NOTES


- If asked for a PIN code when connecting a Bluetooth device, enter <0000>.
- In Bluetooth connection mode, the Bluetooth connection will be lost if the distance between the Soundbar and the Bluetooth device exceeds 10 meters.
- The Soundbar automatically turns off after 20 minutes in the Ready state.
- The Soundbar may not perform Bluetooth search or connection correctly under the following circumstances:
  - If there is a strong electrical field around the Soundbar.
  - If several Bluetooth devices are simultaneously paired with the Soundbar.
  - If the Bluetooth device is turned off, not in place, or malfunctions.
- Electronic devices may cause radio interference. Devices that generate electromagnetic waves must be kept away from the Soundbar main unit - e.g., microwaves, wireless LAN devices, etc.

## 07 CONNECTING AN EXTERNAL DEVICE


Connect to an external device via a wired connection or Bluetooth connection to play the external device's sound through the Soundbar.


### Method 1. Connecting using an HDMI Cable



1. Connect an HDMI cable from the **HDMI IN** port on the bottom of the Soundbar to the HDMI OUT port on your digital device.
2. Connect an HDMI cable from the **HDMI TO TV (ARC)** port on the bottom of the Soundbar to the HDMI IN port on your TV.
3. Press the  (**Source**) button on the top panel or on the remote control, and then select "HDMI".
4. "HDMI" mode is displayed on the Soundbar display panel and sound plays.


## Method 2. Connecting using an Optical Cable




1. Connect **DIGITAL AUDIO IN (OPTICAL)** on the main unit to the OPTICAL OUT port of the Source Device using a digital optical cable (not supplied).
2. Select "**D.IN**" mode by pressing the  (**Source**) button on the top panel or on the remote control.

# 08 CONNECTING A USB STORAGE DEVICE

You can play music files located on USB storage devices through the Soundbar.



1. Connect the USB device to the USB port on the bottom of the product.
2. Press the  (**Source**) button on the top panel or on the remote control, and then select “USB”.
3. “USB” appears in the display screen.
4. Play music files from the USB storage device through the Soundbar.
  - The Soundbar automatically turns off (Auto Power Down) if no USB device has been connected for more than 20 minutes.

## File Format Type Compatibility list

Extension	Codec	Sampling Rate	Bit Rate
*.mp3	MPEG1 Layer2	32kHz ~ 48kHz	32kbps ~ 320kbps
	MPEG1 Layer3	32kHz ~ 48kHz	32kbps ~ 320kbps
	MPEG2 Layer3	16kHz ~ 24kHz	8kbps ~ 160kbps
	MPEG2.5 Layer3	8kHz ~ 12kHz	8kbps ~ 160kbps
*.wma	WMA7/8/9	32kHz ~ 48kHz	32kbps ~ 320kbps
*.ogg	Vorbis	32kHz ~ 48kHz	45kbps ~ 500kbps
*.aac *.m4a	AAC-LC (MPEG2/MPEG4 Audio Only)	32kHz ~ 48kHz	32kbps ~ 320kbps
*.wav	LPCM	32kHz ~ 192kHz	1,024kbps ~ 9,216kbps
*.flac	FLAC	32kHz ~ 192kHz	162kbps ~ 8,100kbps
*.aiff	AIFF	32kHz ~ 192kHz	1,024kbps ~ 9,216kbps


- If there are too many folders (about 200) and files (about 2000) stored on the USB device, it may take the Soundbar some time to access and play files.
- The Soundbar only supports USB devices with FAT16 (~2GB), FAT32 (~2TB) or NTFS (~2TB) file systems.

# 09 CONNECTING A MOBILE DEVICE

## Connecting via Bluetooth

When a mobile device is connected using Bluetooth, you can hear stereo sound without the hassle of cabling.

- The connection is limited to one TV or two Bluetooth devices at the same time.



### The initial connection

1. Press the **PAIR** button on the remote control to enter the “**BT PAIRING**” mode.  
(OR) a. Press the **(Source)** button on the top panel and then select “**BT**”.  
“**BT**” changes to “**BT PAIRING**” in a few seconds automatically or changes to “**BT READY**” if there is a connect record.  
b. When “**BT READY**” appears, press and hold the **(Source)** button on the top panel of the Soundbar for more than 5 seconds to display “**BT PAIRING**”.
2. On your device, select “[AV] Samsung Soundbar B5-Series” from the list that appears.
  - When the Soundbar is connected to the Bluetooth device, [Bluetooth Device Name] → “**BT**” appears in the front display.
3. Play music files from the device connected via Bluetooth through the Soundbar.



### If the device fails to connect

- If a previously connected Soundbar listing (e.g. “[AV] Samsung Soundbar B5-Series”) appears in the list, delete it.
- Then repeat steps 1 and 2.

### NOTE

- After you have connected the Soundbar to your mobile device the first time, use the “**BT READY**” mode to reconnect.

## What is the difference between BT READY and BT PAIRING?

- **BT READY** : In this mode, you can search for previously connected TVs or connect a previously connected mobile device to the Soundbar.
- **BT PAIRING** : In this mode, you can connect a new device to the Soundbar. (Press the  **PAIR** button on the remote control or press and hold the  (**Source**) button on the top of the Soundbar for more than 5 seconds while the Soundbar is in "BT" mode.)

## NOTES

- If asked for a PIN code when connecting a Bluetooth device, enter <0000>.
- In Bluetooth connection mode, the Bluetooth connection will be lost if the distance between the Soundbar and the Bluetooth device exceeds 10 m.
- The Soundbar automatically turns off after 20 minutes in the Ready state.
- The Soundbar may not perform Bluetooth search or connection correctly under the following circumstances:
  - If there is a strong electrical field around the Soundbar.
  - If several Bluetooth devices are simultaneously paired with the Soundbar.
  - If the Bluetooth device is turned off, not in place, or malfunctions.
- Electronic devices may cause radio interference. Devices that generate electromagnetic waves must be kept away from the Soundbar main unit - e.g., microwaves, wireless LAN devices, etc.
- The Soundbar supports SBC data (44.1kHz, 48kHz).
- Connect only to a Bluetooth device that supports the A2DP (AV) function.
- You cannot connect the Soundbar to a Bluetooth device that supports only the HF (Hands Free) function.
- Once you have paired the Soundbar to a Bluetooth device, selecting "[AV] Samsung Soundbar B5-Series" from the device's scanned devices list will automatically change the Soundbar to "BT" mode.
  - Available only if the Soundbar is listed among the Bluetooth device's paired devices.  
(The Bluetooth device and the Soundbar must have been previously paired at least once.)
- The Soundbar will appear in the Bluetooth device's searched devices list only when the Soundbar is displaying "BT READY".

## Bluetooth Power On (SOUND MODE)

If a previously paired Bluetooth device tries to pair with the Soundbar when the Bluetooth Power On function is on and the Soundbar is turned off, the Soundbar turns on automatically.


1. Press and hold the **SOUND MODE** button for more than 5 seconds on the remote while the Soundbar is turned on.
2. "ON-BLUETOOTH POWER" appears on the Soundbar's display.

## Disconnecting the Bluetooth device from a Soundbar

You can disconnect a Bluetooth device from the Soundbar. For instructions, see the Bluetooth device's user manual.

- The Soundbar will be disconnected.
- When the Soundbar is disconnected from the Bluetooth device, the Soundbar will display **"BT DISCONNECTED"** on the front display.

## Disconnecting the Soundbar from the Bluetooth device

Press the  (**Source**) button on the top panel or on the remote control, and then change to any mode except **"BT"**.

- Disconnecting takes time because the Bluetooth device must receive a response from the Soundbar. (Disconnection time may differ, depending on the Bluetooth device)
- When the Soundbar is disconnected from the Bluetooth device, the Soundbar will display **"BT DISCONNECTED"** on the front display.

### **NOTES**

- In Bluetooth connection mode, the Bluetooth connection will be lost if the distance between the Soundbar and the Bluetooth device exceeds 10 m.
- The Soundbar automatically turns off after 20 minutes in the Ready state.

### **More About Bluetooth**

Bluetooth is a technology that enables Bluetooth-compliant devices to interconnect easily with each other using a short wireless connection.

- A Bluetooth device may cause noise or malfunction, depending on usage, if:
  - A part of your body is in contact with the receiving/transmitting system of the Bluetooth device or the Soundbar.
  - It is subject to electrical variation from obstructions caused by a wall, corner, or office partition.
  - It is exposed to electrical interference from same frequency-band devices including medical equipment, microwave ovens, and wireless LANs.
- Pair the Soundbar with the Bluetooth device while they are close together.
- The further the distance between the Soundbar and Bluetooth device, the worse the quality is. If the distance exceeds the Bluetooth operational range, the connection is lost.
- In poor reception areas, the Bluetooth connection may not work properly.
- The Bluetooth connection only works when it is close to the unit. The connection will be automatically cut off if the Bluetooth device is out of range. Even within range, the sound quality may be degraded by obstacles such as walls or doors.
- This wireless device may cause electric interference during its operation.

## Bluetooth Multi connection


The Soundbar can be connected to 2 Bluetooth devices at the same time.




1. Connect the Soundbar to up to two Bluetooth devices. (See page 27)
2. Play music from one of the connected Bluetooth devices while two devices are connected.
3. If music is played from the Bluetooth device “B” while playing from the device “A”, the music is started playing on the device “B” and automatically being stopped/paused playback on the device “A”.
4. In versions prior to AVRCP V1.4, the switching time of the device playing music may be delayed.

## Bluetooth Multi Pairing

### **How to pair multiple devices to the Soundbar**


1. Turn on the Soundbar.
2. Only in “BT” mode, press and hold the  (**Source**) button on the top of the Soundbar for more than 5 seconds for the Soundbar to go into “BT PAIRING” mode, then on the Bluetooth device side, switch Bluetooth on, and select the Soundbar from the list of available devices, the Soundbar will automatically connect to the Bluetooth device.
3. A 2nd Bluetooth device can be paired and connected to the Soundbar using the same method. If you attempt to connect a 3rd device, a connected device that is not playing audio will lose its Bluetooth connection, but will still be paired with the Soundbar.
4. Using the same method, you can pair up to 8 Bluetooth devices, but only the last 2 will stay connected to the Soundbar at the same time.

### **NOTES**


- Only 1 Samsung TV, or 2 Bluetooth devices can be connected to the Soundbar at one time.
- The Soundbar will be disconnected from Bluetooth devices when it receives a connection request from a Samsung TV.
- The default of Soundbar is “**ON-BT MULTI CONNECTION**”, but for restoration to non-multi connection mode from another mode, press and hold the  **PAIR** button on the remote control for more than 5 seconds in standby mode, until “**OFF-BT MULTI CONNECTION**” appears in the display.

# 10 INSTALLING THE WALL MOUNT

## Wallmount Components



Wall Mount Guide



Holder-Screw

Screw




Bracket-Wall Mount

## Installation Precautions

- Install on a vertical wall only.
- Do not install in a place with high temperature or humidity.
- Verify whether the wall is strong enough to support the product's weight. If not, reinforce the wall or choose another installation point.
- Purchase and use the fixing screws or anchors appropriate for the kind of wall you have (plaster board, iron board, wood, etc.). If possible, fix the support screws into wall studs.
- Purchase wall mounting screws according to the type and thickness of the wall you want to mount the Soundbar on.
  - Diameter: M5
  - Length: 35 mm or longer recommended.
- Connect cables from the unit to external devices before you install the Soundbar on the wall.
- Make sure the unit is turned off and unplugged from the power source before you install it. Otherwise, it may cause an electric shock.


1. Place the **Wall Mount Guide** against the wall surface.

- The **Wall Mount Guide** must be level.
- If your TV is mounted on the wall, install the Soundbar at least 5 cm below the TV.




2. Align the **Wall Mount Guide's Centre Line** with the centre of your TV (if you are mounting the Soundbar below your TV), and then fix the **Wall Mount Guide** to the wall using tape.

- If you are not mounting below a TV, place the **Centre Line** in the centre of the installation area.




3. Use a pen to mark the positions of the holes and remove the **Wall Mount Guide**.




4. Using an appropriately sized drill bit, drill a hole in the wall at each marking.
- If the markings do not correspond to the positions of studs, make sure you insert appropriate anchors into the holes before you insert the support screws. If you use anchors, make sure the holes you drill are large enough for the anchors you use.


5. Push a screw (not supplied) through each **Holder-Screw**, and then screw each screw firmly into a support screw hole.




6. Install the 2 **Bracket-Wall Mounts** in the correct orientation on the bottom of the Soundbar using 2 **Screws**.



- When assembling, make sure the hanger part of the **Bracket-Wall Mounts** are located behind the rear of the Soundbar.




7. Install the Soundbar with the attached **Bracket-Wall Mounts** by hanging the **Bracket-Wall Mounts** on the **Holder-Screws** on the wall.




8. Slide the Soundbar down as shown below so that the **Bracket-Wall Mounts** rest securely on the **Holder-Screws**.

- Insert the **Holder-Screws** into the wide (bottom) part of the **Bracket-Wall Mounts**, and then slide the **Bracket-Wall Mounts** down so that the **Bracket-Wall Mounts** rest securely on the **Holder-Screws**.



## 11 SOFTWARE UPDATE


Samsung may offer updates for the Soundbar's system firmware in the future.



If an update is offered, you can update the firmware by connecting a USB device with the firmware update stored on it to the USB port on your Soundbar. For more information about how to download update files, go to the Samsung Electronics website at [www.samsung.com](http://www.samsung.com)→Support.

Then, select the product type or enter the model number of your Soundbar, select the Software & Apps option, and then Downloads. Note that the option names can vary.

### How to check the Firmware version

1. Turn off the Soundbar.
2. Press and hold the  (**Sound Control**) button for about 5 seconds on the remote control.
3. Each version appears in the following order on the Soundbar display.  
(Software version → **HDMI** → **Tx** → **Rx**)
  - **Tx** : Wireless Tx module in the Soundbar.
  - **Rx** : Wireless Rx module in the Subwoofer.
  - **R2 VERSION DISPLAY**
    - No connect rear R2---
    - Connected rear R2xxx

## Update Procedure

**Important:** The update function erases all user settings. We recommend you write down your settings so that you can easily reset them after the update. Note that updating the firmware resets the subwoofer connection too.

1. Connect a USB thumb drive to the USB port on your computer.

**Important:** Make sure there are no music files on the USB thumb drive. This may cause the firmware update to fail.

2. Go to (samsung.com) → select Enter Model Number and enter the model of your Soundbar. Select manuals and downloads and download the latest software file.
3. Save the downloaded software to a USB stick and select “Extract Here” to unzip the folder.
4. Turn off the Soundbar and connect the USB stick containing the software update to the USB port.
5. Turn on the Soundbar and change the source to “**USB**” mode. Within 3 minutes, “**UPDATE**” is displayed and the update begins. When the update is complete, the Soundbar turns off and then turns on automatically.
6. Press the **— + (Volume)** button on the top panel for 5 seconds. “**INIT**” appears on the display and then the Soundbar turns off. The update is complete.
  - This product has a DUAL BOOT function. If the firmware fails to update, you can update the firmware again.
7. Restore your settings on the Soundbar.

## If UPDATE is not displayed

1. Turn off the Soundbar, disconnect and then reconnect the USB storage device that contains the update files to the Soundbar’s USB port.
2. Disconnect the Soundbar’s power cord, reconnect it, and then turn on the Soundbar.

### NOTES

- The firmware update may not work properly if audio files supported by the Soundbar are stored in the USB storage device.
- Do not disconnect the power or remove the USB device while updates are being applied. The main unit will turn off automatically after completing the firmware update.
- After the update is completed, the user setup in the Soundbar is Initialised so you can reset your settings. We recommend you write down your settings so that you can easily reset them after the update. Note that updating firmware resets the subwoofer connection too.

If the connection to the subwoofer is not re-established automatically after the update, refer to page 16.

If the software update fails, check if the USB stick is defective.
- Mac OS users should use MS-DOS (FAT) as the USB format.
- Updating via USB may not be available, depending on the USB storage device manufacturer.

# 12 TROUBLESHOOTING

Before seeking assistance, check the following.

## Soundbar does not turn on.

- Check whether the power cord of the Soundbar is correctly inserted into the outlet.

## Soundbar works erratically.

- After removing the power cord, insert it again.
- Power cycle the external device and try again.
- If there is no signal, the Soundbar automatically turns off after a certain period of time. Turn on the power. (See page 7.)

## If the remote control does not work.

- Point the remote directly at the Soundbar.
- Replace the batteries with new ones.

## Soundbar does not output any sound.

- The volume of the Soundbar is too low or muted. Adjust the volume.
- When any external device (STB, Bluetooth device, mobile device, etc.) is connected, adjust the volume of the external device.
- For sound output of the TV, select Soundbar. (Samsung TV: Home (🏠) → Menu → Settings (⚙️) → All Settings (⚙️) → Sound → Sound Output → Select Soundbar)
- The cable connection to the Soundbar may not be loose. Remove the cable and connect again.
- Remove the power cord completely, reconnect, and turn the power on.
- Reset the product and try again. (See page 34.)

## Subwoofer does not output any sound.

- Check whether the LED indicator on the rear of the Subwoofer is on in blue. Reconnect the Soundbar and Subwoofer if the indicator is blinking in blue or turned red. (See page 17.)
- You may experience an issue if there is an obstacle between the Soundbar and Subwoofer. Move devices to an area away from obstacles.
- Other devices sending radio frequency signals in proximity may interrupt the connection. Keep your speaker away from such devices.
- Remove and reconnect the power plug.

## The Subwoofer volume is too low.

- The original volume of the content you are playing may be low. Try adjusting the Subwoofer level. (See page 12.)
- Bring the Subwoofer speaker closer to you.



## If the TV is not connected via HDMI TO TV (ARC).

- Check whether the HDMI cable is correctly connected to the ARC terminal. (See page 19.)
- Connection may not be possible due to the connected external device (set-top box, game machine, etc.). Directly connect the Soundbar.
- HDMI-CEC may not be activated on the TV. Turn on the CEC on the TV menu. (Samsung TV: Home (🏠) → Menu → Settings (⚙️) → All Settings (⚙️) → Connection → External Device Manager → Anynet+ (HDMI-CEC) ON)

### There is no sound in when connecting to the TV in HDMI TO TV (ARC) mode.

- Your device is unable to play the input signal. Change the TV's audio output to PCM or Dolby Digital.  
(For a Samsung TV: Home (🏠) → Menu → Settings (⚙️) → All Settings (⚙️) → Sound → Expert Settings → Digital Output Audio Format)

### Soundbar does not connect via Bluetooth.

- When connecting a new device, switch to "BT PAIRING" for connection. (Press the  PAIR button on the remote control or press the  (Source) button on the body for at least 5 seconds.)
- If the Soundbar is connected to another device, disconnect that device first to switch the device.
- Reconnect it after removing the Bluetooth speaker list on the device to connect.  
(Samsung TV: Home (🏠) → Menu → Settings (⚙️) → All Settings (⚙️) → Sound → Sound Output → Bluetooth Speaker List)
- The automatic TV connection may be disabled. While the Soundbar is in "BT READY", press and hold the **Left** button on the Soundbar remote control for 5 seconds to select **ON-TV CONNECT**. If you see **OFF-TV CONNECT**, press and hold **Left** button again for 5 seconds to switch the selection.
- Remove and reconnect the power plug, then try again.
- Reset the product and try again.  
(See page 34.)

### Sound drops out when connected via Bluetooth.

- If your device that is connected via Bluetooth moves too far away from the Soundbar, it may cause the sound to drop out. Move the device closer to the Soundbar.
- If a part of your body is in contact with the Bluetooth transceiver or the product is installed on metal furniture, sound may drop out. Check the installation environment and conditions for use.

### Bluetooth multi connection does not work.

- When the TV is connected to the soundbar, Bluetooth multi connection may not operate. Disconnect the Soundbar from the TV and try again.
- Check whether the Bluetooth Multi connection setting is turned on.  
(Refer to the "**Soundbar does not connect via Bluetooth.**" section.)
- Disconnect the device currently playing, pair with the device that you want to connect, and reconnect the previous device.
- If the sound is inaudible even after connecting properly, refer to the "**Sound drops out when connected via Bluetooth.**" section.

### Soundbar does not turn on automatically with the TV.

- When you turn off the Soundbar while watching TV, power synchronization with the TV is disabled. First turn off the TV.

# 13 LICENCE



Manufactured under license from Dolby Laboratories. Dolby, Dolby Audio and the double-D symbol are trademarks of Dolby Laboratories Licensing Corporation.



For DTS patents, see <http://patents.dts.com>.  
Manufactured under license from DTS Licensing Limited. DTS, the Symbol, DTS in combination with the Symbol, DTS and the Symbol together, Virtual:X, the DTS Virtual:X logo, and DTS 2.0 Channel are registered trademarks or trademarks of DTS, Inc. in the United States and/or other countries. © DTS, Inc. All Rights Reserved.



The terms HDMI and HDMI High-Definition Multimedia Interface, and the HDMI Logo are trademarks or registered trademarks of HDMI Licensing Administrator, Inc. in the United States and other countries.



The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Samsung Electronics Co., Ltd. is under license. Other trademarks and trade names are those of their respective owners.



---

## [ENERGY STAR]

### ENERGY STAR qualified model only

- Your Samsung product is ENERGY STAR qualified in its factory default setting. Change to certain features, settings and functionality in this product can change the power consumption, possibly beyond the limits required for ENERGY STAR qualification.
- Environmental Protection Agency and Department of Energy. ENERGY STAR is a joint program of the Government agencies, designed to promote energy efficient products and practices.

Refer to [www.energystar.gov](http://www.energystar.gov) for more information of the ENERGY STAR Program.

### ENERGY STAR qualified model only (Applicable to Thin Client models only)

As an ENERGY STAR® Partner, SAMSUNG has determined that this product meets the ENERGY STAR® guidelines for energy efficiency.

- The ENERGY STAR Program has been to reduced greenhouse gas emissions and save energy through voluntary labeling.
- Power management setting of this product have been enabled by default, and have various timing setting from 1 minutes to 5 hours.
- The product can wake with a button press on the chassis from sleep mode.

### ENERGY STAR qualified model only (The other models)

- As an ENERGY STAR Partner, Samsung has determined that this product or product models meets the ENERGY STAR guideline for energy efficiency.

## **14 OPEN SOURCE LICENCE NOTICE**

To send inquiries and requests for questions regarding open sources, contact Samsung Open Source (<http://opensource.samsung.com>)

## **15 IMPORTANT NOTES ABOUT SERVICE**

Figures and illustrations in this User Manual are provided for reference only and may differ from actual product appearance.

# 16 SPECIFICATIONS AND GUIDE

## Specifications

Model Name	HW-B550
USB	5V/0.5A
Weight	2.1 kg
Dimensions (W x H x D)	860.0 x 59.4 x 75.0 mm
Operating Temperature Range	+5°C to +35°C
Operating Humidity Range	10 % ~ 75 %
AMPLIFIER Rated Output power	160W(40Wx4)
Supported play formats (DTS 2.0 and DTS Virtual:X sound are played in DTS format.)	LPCM 2ch, Dolby Audio™ (supporting Dolby® Digital), DTS, DTS Virtual:X

Subwoofer Name	PS-WB65D
Weight	5.1 kg
Dimensions (W x H x D)	184.0 x 346.0 x 295.0 mm
AMPLIFIER Rated Output power	250W

### NOTES

- Samsung Electronics Co., Ltd reserves the right to change the specifications without notice.
- Weight and dimensions are approximate.

# 安全資訊

## 安全警告

為防止電擊，請勿拆卸蓋板 (或背板)。  
本機內部無使用者可以自行維修的零件。如需維修，請由專門的服務人員進行維修。  
參閱下表，以取得三星產品上標誌的詮釋。

	<div>注意</div> <div>為防止電擊，請勿打開。</div>	
	此符號表示內有高電壓。以任何方式與本產品內部之任何部件接觸均可導致危險。	
	此符號表示本產品隨附關於操作與維護的重要說明文件。	
	II 類產品：此符號表示不需要連接接地。 如此標誌沒有在帶有電源線的產品上出現，則產品必須正確連接保護地線。	
	AC 電壓：此符號表示額定電壓的標記為 AC 電壓。	
	DC 電壓：此符號表示額定電壓的標記為 DC 電壓。	
	注意，使用時需參照說明指示：此符號指示用戶查閱使用者手冊以取得進一步的安全相關資訊。	

## 警告

- 請勿將本機暴露在雨中或潮濕場所，以免火災或電擊。

## 注意

- 為防止電擊，請將寬片插頭完全插入匹配的寬插槽。
- 本設備應始終連接到帶有保護地線連接的交流電插座。
- 設備與電源斷開連接時，必須將插頭從電源插座上拔出，因此電源插頭應隨時保持便於操作。
- 請勿將水滴落或噴灑在設備上，不得在設備上放置裝有液體的物品，如花瓶。
- 要完全關閉本設備，須將電源插頭從牆上電源插座拔出。因此，電源插頭應隨時保持便於操作。

# 注意事項

1. 確定您屋內的交流電源供應符合產品底部識別標籤上列出的電源要求。請將產品安裝在水平、適當的基座 (家具) 上，並在周邊留下足夠的通風空間 7~10 公分。確保通風孔未被堵塞。請勿將本設備放在放大器或其他會發熱的設備上。本設備可供連續使用。要完全斷開設備的電源連接，請從牆上電源插座上拔掉交流電插頭。如果長時間不使用設備，請拔下其電源插頭。
2. 在雷雨天氣時，請從牆上電源插座拔下交流電插頭。閃電造成的電壓峰值會損壞本設備。
3. 請勿將本設備直接在陽光下暴曬或暴露於其他熱源下。這可能導致本設備過熱而發生故障。
4. 本產品應避免接觸潮濕 (如花瓶) 以及過熱 (如壁爐) 或者會產生強磁或電場的設備。如果設備發生故障，請從交流電源拔下電源線。本產品並非供工業使用，而是僅供個人使用。如果本產品存放在低溫環境中，則可能會出現冷凝現象。如果在冬天將本設備運送到室內，則需要等待大約 2 小時的時間，以便本機在使用前達到室內溫度。

5. 本產品使用的電池含有對環境有害的化學物質。請勿將電池作為普通生活垃圾棄置。請勿將電池置於火中。請勿使電池短路，分解或過熱。


**注意：**如果沒有正確替換電池，可能會導致危險。僅可使用同樣或相同類別的電池替換。

# 目錄

01	查看元件	6
02	產品概覽	7
	Soundbar 的前方面板/上方面板	7
	Soundbar 底部面板	8
03	使用遙控器	9
	使用遙控器前插入電池 (2 粒 AAA 電池)	9
	使用遙控器的方法	9
	使用隱藏按鈕 (具有多個功能的按鈕)	13
	不同音效模式的輸出規格	13
	使用電視遙控器調校 Soundbar 音量	14
04	連接 Soundbar	15
	連接電源	15
	將 Soundbar 連接至低音炮	16
	將 Samsung 無線後置套件連接至 Soundbar	18
05	使用纜線連接至電視	19
	方法 1。使用 HDMI 線連接電視	19
	方法 2。使用光纖線連接	21
06	以無線方式連接至電視	22
	透過藍牙連接	22

07	連接外部裝置	24
	方法 1。使用 HDMI 線連接	24
	方法 2。使用光纖線連接	25
08	連接 USB 儲存裝置	26
09	連接流動裝置	27
	透過藍牙連接	27
10	安裝牆壁安裝托架	31
	安裝注意事項	31
	牆壁安裝托架元件	31
11	軟件更新	33
	如何檢查韌體版本	33
	更新程序	34
	若「更新」沒有顯示	34
12	解決疑難	35
13	授權	37
14	開源軟件許可聲明	38
15	有關維修的重要說明	38
16	規格和指南	39
	規格	39


# 01 查看元件



- 如需更多有關電源供應和耗電資料，請參閱產品貼附標籤。  
(標籤：Soundbar 主設備底部)
- 如欲購買其他元件或連接線，請聯絡 Samsung 服務中心或 Samsung 客戶服務中心。
- AC 插頭的外觀可能視乎地區而定，或與 AC/DC 適配器整合提供。
- 配件的外觀與上圖可能有些不同。
- 設計和規格畫面可能會隨時變更，恕不另行通知。

# 02 產品概覽


## Soundbar 的前方面板/上方面板



1	<b>顯示螢幕</b> 顯示產品狀態和目前模式。												
2	<b>⏻ (電源) 按鈕</b> 開啟或關閉電源。 <ul style="list-style-type: none"><li>• <b>Auto Power Down 功能</b> 裝置會在以下情況下自動關閉。<ul style="list-style-type: none"><li>- D.IN / HDMI / BT / USB 模式：若 20 分鐘沒有音訊。</li></ul></li></ul>												
3	<b>— + (音量) 按鈕</b> 調整音量。 <ul style="list-style-type: none"><li>• 調整時，音量會在 Soundbar 的前方顯示螢幕上出現。</li></ul>												
4	<b>↺ (來源) 按鈕</b> 選擇來源輸入模式。 <table><tr><th>輸入模式</th><th>顯示螢幕</th></tr><tr><td>光纖數位輸入</td><td>D.IN</td></tr><tr><td>ARC (HDMI OUT) 輸入</td><td>D.IN → TV ARC (自動轉換)</td></tr><tr><td>HDMI 輸入</td><td>HDMI</td></tr><tr><td>BLUETOOTH 模式</td><td>BT</td></tr><tr><td>USB 模式</td><td>USB</td></tr></table> <ul style="list-style-type: none"><li>• 如要開啟「BT PAIRING」模式，將來源變更為「BT」模式，然後按住 <b>↺ (來源) 按鈕</b> 超過 5 秒。</li></ul>	輸入模式	顯示螢幕	光纖數位輸入	D.IN	ARC (HDMI OUT) 輸入	D.IN → TV ARC (自動轉換)	HDMI 輸入	HDMI	BLUETOOTH 模式	BT	USB 模式	USB
輸入模式	顯示螢幕												
光纖數位輸入	D.IN												
ARC (HDMI OUT) 輸入	D.IN → TV ARC (自動轉換)												
HDMI 輸入	HDMI												
BLUETOOTH 模式	BT												
USB 模式	USB												

- 插入交流電電源線時，電源按鈕會在 4 至 6 秒後開始運作。
- 開啟本設備時，您需要等待 4 至 5 秒才會聽到聲音。
- 如果您只想透過 Soundbar 聆聽音訊，則必須在電視的「自動設定」選單中關閉電視揚聲器。請參閱您電視隨附的使用者手冊。

# Soundbar 底部面板




<b>1</b>	<b>DIGITAL AUDIO IN (OPTICAL)</b> 連接至外部裝置的數位 (光纖) 輸出。
<b>2</b>	<b>USB (5V 0.5A)</b> 在此連接 USB 裝置以透過 Soundbar 播放 USB 裝置上的音樂檔案。
<b>3</b>	<b>HDMI IN</b> 使用 HDMI 線同時輸入數碼視頻和音頻訊號。 連接至外部裝置的 HDMI 輸出。
<b>4</b>	<b>HDMI TO TV (ARC)</b> 連接至電視上的 HDMI (ARC) 插孔。
<b>5</b>	<b>DC 24V (電源供應輸入)</b> 連接交流/直流電適配器。

- 從牆上插座解除連接交流/直流電源適配器的電源線時，拉出插頭。  
不要拉扯電源線。
- 元件之間完成所有連接之前，不要將本設備或其他元件連接至交流電插座。


# 03 使用遙控器

## 使用遙控器前插入電池 (2 粒 AAA 電池)

向箭頭方向滑動背蓋，直至將其完全移除。以正確電極方向插入 2 粒 AAA 電池 (1.5V)。  
將背蓋滑動回原位。





## 使用遙控器的方法





1	 電源	開啟和關閉 Soundbar。
2	 來源	按下以選擇連接至 Soundbar 的來源。
3	 靜音	按下  (靜音) 按鈕即可設為靜音。 再次按下按鈕即可取消靜音。
4	 音量	 將按鈕向上或向下推，以調整音量。 <ul style="list-style-type: none"><li>• 靜音 按下 <b>音量</b> 按鈕以設定為靜音。再次按下按鈕以取消靜音。</li></ul>

<b>5</b>	 <b>CH LEVEL</b>	<p>按下按鈕，即可調較各揚聲器的音量。</p> <ul style="list-style-type: none"> <li>• 按下按鈕以選擇 <b>VIRTUAL CENTER LEVEL</b>，以及使用<b>上/下</b>按鈕來設定，以將的音量在 -6 至 +6 之間進行調整。</li> <li>• 連接後置揚聲器 (單獨出售) 時，可支援 <b>REAR LEVEL</b> 設定。使用<b>上/下</b>按鈕來設定，以將的 <b>REAR LEVEL</b> 的音量在 -6 至 +6 之間進行調整。</li> </ul>
<b>6</b>	 <b>聲音控制</b>	<p>按下按鈕，即可設定音訊功能。 可使用<b>上/下</b>鈕設整所需的設定。</p> <p><b>AUDIO SYNC → NIGHT MODE ON/OFF → VOICE ENHANCE ON/OFF</b></p> <ul style="list-style-type: none"> <li>- <b>AUDIO SYNC</b> 如果電視影片和 Soundbar 音訊並非同步，按下  (<b>聲音控制</b>) 按鈕來選擇 <b>AUDIO SYNC</b>，然後使用<b>上/下</b>按鈕將音訊延遲設定為 0~300 毫秒之間。(不適用於「USB」或「BT」模式。)</li> <li>- <b>NIGHT MODE ON/OFF</b> 此模式針對夜間觀看作出最佳化，已調整設定以降低音量，同時保持對話清晰。</li> <li>- <b>VOICE ENHANCE ON/OFF</b> 此模式讓您更可輕鬆地聽到電影和電視播放的語音對話。</li> <li>• <b>NIGHT MODE</b> 和 <b>VOICE ENHANCE</b> 功能可透過<b>上/下</b>鈕來 ON/OFF。</li> <li>• 按住  (<b>聲音控制</b>) 按鈕 5 秒，為各頻段調整音效。可使用<b>左/右</b>按鈕選擇 150Hz、300Hz、600Hz、1.2kHz、2.5kHz、5kHz 和 10kHz，而各頻率可使用<b>上/下</b>按鈕在 -6 至 +6 之間進行設定。 (請確保聲音模式已設置為「STANDARD」。)</li> </ul>
<b>7</b>	 <b>Bluetooth PAIR</b>	<p>切換 Soundbar 至藍牙配對模式。</p> <p>按下  <b>PAIR</b> 按鈕直至出現 <b>BT PAIRING</b> 畫面，以連接新的藍牙裝置。</p>
<b>8</b>	 <b>播放/暫停</b>	<p>按下按鈕即可播放或暫停播放音樂。</p>

<div data-bbox="87 87 114 119">9</div>	<div data-bbox="145 92 255 199"></div> <div data-bbox="143 210 255 239">上/下/左/右</div>	<div data-bbox="288 97 432 240"></div> <div data-bbox="453 156 777 185">按下指示區域以選擇上/下/左/右。</div> <p data-bbox="282 263 717 290">在按鈕上按下上/下/左/右以選擇或設定功能。</p> <ul data-bbox="288 304 1025 582" style="list-style-type: none"> <li data-bbox="288 304 1025 363"> <b>重覆</b>            如要在「USB」模式下使用重覆功能，按下<b>上</b>按鈕。         </li> <li data-bbox="288 373 1025 475"> <b>音樂跳播</b>            按下<b>右</b>按鈕以選擇下一個音樂檔案。按下向<b>左</b>按鈕以選擇上一個音樂檔案。         </li> <li data-bbox="288 485 1025 582"> <b>ID SET</b>            按住<b>上</b>按鈕 5 秒，以完成 <b>ID SET</b> (連接無線有源重低音音箱或無線後置揚聲器的時候。)         </li> </ul>
<div data-bbox="87 603 114 635">10</div>	<div data-bbox="165 603 236 671"></div> <div data-bbox="176 683 225 711">資料</div>	<p data-bbox="282 603 792 630">按下後，便會顯示各種模式的資料。(請參閱第 7 頁。)</p>

11	 <p><b>SOUND MODE</b></p>	<p>按下按鈕，即可選擇所需的聲音模式。</p> <p><b>SURROUND SOUND → BASS BOOST → GAME → ADAPTIVE → DTS VIRTUAL:X → STANDARD</b></p> <ul style="list-style-type: none"> <li>– <b>SURROUND SOUND</b> 提供比標準更寬闊的音場。</li> <li>– <b>BASS BOOST</b> 聲場模式強調低音。</li> <li>– <b>GAME</b> 提供立體聲，讓您在玩遊戲時盡情投入。</li> <li>– <b>ADAPTIVE</b> 即時分析內容，並自動根據內容特性提供最佳音場。</li> <li>– <b>DTS VIRTUAL:X</b> 任何內容都能帶來逼真立體聲。</li> <li>– <b>STANDARD</b> 輸出原始聲音。</li> <li>• <b>DRC (Dynamic Range Control)</b> 讓您將動態範圍控制套用至 Dolby Digital 歌曲。Soundbar 關閉時，按住 <b>SOUND MODE</b> 按鈕 5 秒，即可開啟或關閉 DRC (動態範播控制)。開啟 DRC 後，音量會降低。(聲音可能會失真。)</li> <li>• <b>Bluetooth Power</b> 此功能可在收到先前已連接的電視或藍牙裝置的連接要求時自動開啟 Soundbar。設定預設為開啟。 <ul style="list-style-type: none"> <li>– 按住 <b>SOUND MODE</b> 按鈕超過 5 秒，以關閉 Bluetooth Power 功能。</li> </ul> </li> </ul>
12	 <p><b>WOOFER (BASS) 水平</b></p>	<div data-bbox="284 903 734 1062">  </div> <p>將按鈕向上或向下推，以調整 -12 或 -6 至 +6 的低音炮 (低音) 水平。如要將低音炮 (低音) 音量設為 0 (預設)，按下按鈕。</p>
13	 <p><b>TONE CONTROL</b></p>	<p>按下按鈕，即可調較高音或低音的音量。</p> <ul style="list-style-type: none"> <li>• 按下按鈕以選擇 <b>TREBLE</b> 或 <b>BASS</b>，以及使用上/下按鈕來設定，以將的音量在 -6 至 +6 之間進行調整。</li> </ul>

# 使用隱藏按鈕 (具有多個功能的按鈕)

隱藏按鈕		參考網頁
遙控器按鈕	功能	
WOOFER (上)	電視遙控器開/關 (備用)	第 14 頁
左	電視自動連接開/關 (藍牙準備就緒)	第 23 頁
上	ID SET	第 11 頁
 (聲音控制)	7 頻 EQ	第 10 頁
SOUND MODE	DRC ON/OFF (備用)	第 12 頁
	Bluetooth Power	第 12 頁
 PAIR	Bluetooth 多重連接開啟/關閉 (備用)	第 30 頁

## 不同音效模式的輸出規格

效果		輸入	輸出	
			不包含無線後置揚聲器 套件	包含無線後置揚聲器套 件
 SOUND MODE	SURROUND SOUND	2.0 ch	2.1 ch	4.1 ch
		5.1 ch	2.1 ch	4.1 ch
	BASS BOOST	2.0 ch	2.1 ch	4.1 ch
		5.1 ch	2.1 ch	4.1 ch
	GAME	2.0 ch	2.1 ch	4.1 ch
		5.1 ch	2.1 ch	4.1 ch
	ADAPTIVE	2.0 ch	2.1 ch	4.1 ch
		5.1 ch	2.1 ch	4.1 ch
	DTS VIRTUAL:X	2.0 ch	2.1 ch	4.1 ch
		5.1 ch	2.1 ch	4.1 ch
	STANDARD	2.0 ch	2.1 ch	2.1 ch
		5.1 ch	2.1 ch	2.1 ch







- Samsung 無線後置揚聲器套件獨立發售。如要選購套件，請聯絡您購買 Soundbar 的供應商。

# 使用電視遙控器調校 Soundbar 音量

使用電視遙控器調校 Soundbar 音量。

- 此功能只可以與 IR 遙控器一併使用。藍牙遙控器 (需要進行配對的遙控器) 不受支援。
- 將電視揚聲器設定至**外部揚聲器**以使用此功能。
- 支援該功能的製造商：  
Samsung, VIZIO, LG, Sony, Sharp, PHILIPS, PANASONIC, TOSHIBA, Hisense, RCA

1. 關閉 Soundbar。
2. 按住 **WOOFER** 按鈕 5 秒。  
每次向上推動 **WOOFER** 按鈕 5 秒時，模式會按以下次序切換：「**OFF-TV REMOTE**」(預設模式)、「**SAMSUNG-TV REMOTE**」、「**ALL-TV REMOTE**」。

遙控器按鈕	顯示	狀態
	(預設模式) 	停用電視遙控器。
		啟用三星電視的 IR 遙控器。
		啟用第三方電視的 IR 遙控器。

## 04 連接 SOUNDBAR


### 連接電源

使用電源元件 將低音炮和 Soundbar 按以下次序連接至電源插座：

1. 將電源線連接至低音炮。
2. 將電源輸出線連接至電源適配器，然後連接至 Soundbar。
3. 將電源線連接至牆上插座。

參閱下圖。

- 如需更多有關電源功率需求和耗電資料，請參閱產品標籤。  
(標籤：Soundbar 主設備底部)



- 請確保交流電/直流電適配器平穩放在桌面上或地上。若您將交流電/直流電適配器的交流電源線插口朝上懸掛，水或其他異物可能進入適配器而導致其無法正常工作。

# 將 Soundbar 連接至低音炮

連接低音炮後，您可享受豐富的重低音。

## 自動連接低音炮和 Soundbar

將電源線連接至 Soundbar 和低音炮並開啟電源後，低音炮會自動連接至 Soundbar。

- 自動配對完成後，有源重低音音箱後方的藍色指示燈會亮起。

## 低音炮後方的 LED 指示燈

LED	狀態	描述	解決方法
	開	成功連接 (正常操作)	-
	閃爍	正在恢復連接	檢查電源線是否已正確連接 Soundbar 主設備，或等待約 5 分鐘。若指示燈持續閃爍，嘗試手動連接低音炮。請參閱第 17 頁。
	開	待機 (Soundbar 主設備已關閉)	檢查電源線是否已正確連接 Soundbar 主設備。
		連接失敗	重新連接。參閱第 17 頁的手動連接指示。
	閃爍	故障	參閱本手冊的 Samsung 服務中心聯絡資料。


## 自動連接失敗時，手動連接低音炮

執行下方手動連接程序前：

- 檢查 Soundbar 和低音炮的電源線是否正確連接。
- 確定 Soundbar 已開啟。


1. 按住低音炮後方的 **ID SET** 最少 5 秒。

- 低音炮後方的紅色指示燈熄滅，藍色指示燈閃爍。




2. 按住遙控器上的上按鈕最少 5 秒。

- Soundbar 顯示螢幕上將顯示 **ID SET** 訊息，然後在短時間內消失。
- **ID SET** 完成後，Soundbar 會自動開啟。



3. 檢查 LINK LED 亮起藍色 (連接完成)。



Soundbar 和無線低音炮連接後，LINK LED 指示燈停止閃爍並亮起藍色。

## 備註

- 元件之間完成所有連接之前，不要將本產品或電視的電源線連接至牆上的插座。
- 移動或安裝本產品時，確保關閉電源，並解除連接電源線。
- 如果主裝置的電源關閉，無線低音炮將處於待機模式，並且背後的 STANDBY LED 將會閃爍藍色數次，然後轉為紅色。
- 如果您在 Soundbar 附近使用與 Soundbar 相同頻率 (5.8GHz) 的裝置，干擾可能會導致部分聲音中斷。
- 主設備的無線訊號最大傳輸距離約為 10 米，但可能視乎您的運作環境而定。若主設備和無線低音炮之間受鋼筋混凝土或金屬牆阻隔，系統可能無法運作，因為無線訊號無法穿過金屬。

## 注意事項

- 無線低音炮內置無線接收天線。讓設備遠離水和濕氣。
- 如要取得最佳聆聽體驗，請確定無線低音炮附近和無線接收器模組 (獨立發售) 位置沒有任何障礙物。

## 將 Samsung 無線後置套件連接至 Soundbar

透過將 Samsung 無線後置揚聲器套件 (SWA-9100S 或 SWA-9200S，獨立發售) 連接至有 Soundbar，可擴大至逼真的無線環繞聲。

有關如何連接的詳細資料，請參閱 Samsung 無線後置揚聲器套件的手冊。

## 05 使用纜線連接至電視


透過有線和無線連接在 Soundbar 上收聽電視聲音。

- Soundbar 連接至指定的 Samsung 電視後，您便可使用電視遙控器控制 Soundbar。
  - 2017 或以後支援藍牙的 Samsung Smart TV 支援此功能，您需使用光纖線將 Soundbar 連接至電視。
  - 此功能亦讓您使用電視選單調整音場和各種設定，以及音量和靜音。


### 方法 1。使用 HDMI 線連接電視

#### ⚠ 注意

- 同時連接 HDMI 纜線和光纖電纜時，會首先接收 HDMI 訊號。
- 如要連接電視和 Soundbar 之間的 HDMI 纜線，請確保連接標示為 ARC 的端子。否則可能不會輸出電視聲音。
- 建議使用 **High-Speed HDMI Cable with Ethernet**。



1. 開啟 Soundbar 和電視後，按照圖解所示連接 HDMI 線。
2. 「TV ARC」在 Soundbar 主設備的顯示螢幕上出現，而 Soundbar 會播放電視聲音。

- 如果聽不到電視聲音，按下遙控器上的  (來源) 按鈕或 Soundbar 頂部，以切換至「D.IN」模式。螢幕會按序顯示「D.IN」和「TV ARC」，而電視聲音會播放。
- 如果「TV ARC」沒有出現在 Soundbar 主設備的顯示螢幕上，請確定 HDMI 線已插入正確的連接埠。
- 使用電視遙控器上的音量按鈕變更 Soundbar 音量。


#### 備註


- HDMI 是以單一接頭進行影片和音訊資料數碼傳輸的介面。
- 若電視配備 ARC 連接埠，將 HDMI 線連接至 HDMI IN (ARC) 連接埠。
- 我們建議您盡可能使用無芯 HDMI 線。如果您使用帶芯 HDMI 線，請使用直徑少於 14 毫米的 HDMI 線。
- 若 HDMI 線不支援 ARC，此功能將無法使用。
- 若廣播的音訊以 Dolby Digital 編碼，且電視上的「數碼輸出音訊格式」設定為 PCM，我們建議您將設定變更為 Dolby Digital。電視設定變更後，您可享受有較佳的音質。(電視菜單可能使用不同文字顯示 Dolby Digital 和 PCM，視乎電視製造商而定。)

## 方法 2。使用光纖線連接

### 連接前的檢查清單

- 同時連接 HDMI 纜線和光纖電纜時，會首先接收 HDMI 訊號。
- 如果所採用的光纖電纜端子有蓋，請僅記移除端子口。




1. 使用數位光纖連 (未提供) 接線連接 Soundbar 上的 **DIGITAL AUDIO IN (OPTICAL)** 插孔和電視的 **OPTICAL OUT** 插孔。
2. 按下上方面板或遙控器上的  (來源) 按鈕，然後選擇「D.IN」模式。

## 06 以無線方式連接至電視

### 透過藍牙連接

透過藍牙連接電視時，您可以欣賞立體聲，而無需因處理纜線而煩惱。

- 只可同時連接一部電視。



### 初始連接

1. 按下遙控器上的 **PAIR** 按鈕，以進入「BT PAIRING」模式。  
(或)
  - a. 按下上方面板的 **↵ (來源)** 按鈕，然後選擇「BT」。  
「BT」會在數秒內自動轉為「BT PAIRING」，若有連接記錄則會轉為「BT READY」。
  - b. 看到「BT READY」時，按住 Soundbar 上方面板上的 **↵ (來源)** 按鈕超過 5 秒，以顯示「BT PAIRING」。
2. 在電視上選擇藍牙模式。(如需瞭解詳情，請參閱電視手冊。)
3. 從電視螢幕上的清單選擇「[AV] Soundbar B5-Series」。  
可用的 Soundbar 會在電視藍牙裝置清單上顯示為「需要配對」或「已配對」。  
如要連接 Soundbar，選擇訊息並建立連接。
  - 電視連接後，[電視名稱] → 「BT」會在 Soundbar 前方顯示螢幕上出現。
4. 您現在可以聽到 Soundbar 播放電視聲音。


### 若裝置無法連接

- 如果先前連接的 Soundbar (例如「[AV] Soundbar B5-Series」) 在清單上出現，請將它刪除。
- 然後重複第 1 至 3 步。

### 注意



- 首次將 Soundbar 連接至電視後，可使用「BT READY」模式重新連接。

## 從電視解除連接 Soundbar

按下上方面板或遙控器上的  (來源) 按鈕，然後將模式變更為「BT」以外的模式。

- 電視必須從 Soundbar 接收回應，因此解除連接過程需要時間。  
(所需時間可能有所不同，視乎電視型號而定。)
- 如要取消 Soundbar 和電視之間的自動藍牙連接，在 Soundbar 處於「BT READY」狀態時，按下遙控器上的左按鈕 5 秒。(切換開 → 關)

## BT READY 和 BT PAIRING 有什麼不同？

- **BT READY**：在這個模式，您可以搜尋先前已連接的電視，或將先前已連接的流動裝置連接至 Soundbar。
- **BT PAIRING**：在這個模式，您可以將新裝置連接至 Soundbar。(按下遙控器上的  PAIR 按鈕，或在 Soundbar 處於「BT」模式時按住 Soundbar 上方面板的  (來源) 按鈕超過 5 秒。)


## 備註


- 如果系統在連接藍牙裝置時要求輸入 PIN 碼，請輸入 <0000>。
- 在藍牙連接模式下，若 Soundbar 和藍牙裝置相距超過 10 米，藍牙連接會中斷。
- 在待機狀態下，Soundbar 會在 20 分鐘後自動關閉。
- 在以下情況下，Soundbar 可能不會執行藍牙搜尋，或正確連接：
  - 若 Soundbar 附近的電場強烈。
  - 當同時有兩個或更多的藍牙裝置與 Soundbar 配對。
  - 若藍牙裝置已關閉、不存在或發生故障。
- 電子裝置可能會導致無線電干擾。發放電磁波的裝置必須與 Soundbar 主設備保持遠距離，當中包括微波爐、無線 LAN 裝置等。

## 07 連接外部裝置


使用連接線或藍牙連接至外部裝置，以透過 Soundbar 播放外部裝置的聲音。


### 方法 1：使用 HDMI 線連接



1. 使用 HDMI 纜線連接 Soundbar 底部的 **HDMI** 連接埠和相關數位裝置的 HDMI OUT 連接埠。
2. 使用 HDMI 纜線連接 Soundbar 底部的 **HDMI TO TV (ARC)** 連接埠和相關電視的 HDMI IN 連接埠。
3. 按下上方面板或遙控器上的  (來源) 按鈕，然後選擇「HDMI」。
4. 「HDMI」模式會在 Soundbar 顯示面板上顯示，而聲音會播放。


## 方法 2。使用光纖線連接




1. 使用數位光纖連 (未提供) 接線連接主設備上的 **DIGITAL AUDIO IN (OPTICAL)** 和外部裝置的 **OPTICAL OUT** 插孔。
2. 按下上方面板或遙控器上的  (來源) 按鈕，以選擇「D.IN」模式。

# 08 連接 USB 儲存裝置

您可以透過 Soundbar 播放位於 USB 儲存裝置上的音樂檔案。



- 1. 經由產品底部的 USB 插口連接 USB 裝置。
- 2. 按下上方面板或遙控器上的  (來源) 按鈕，然後選擇「USB」。
- 3. 「USB」會顯示在螢幕上。
- 4. 透過 Soundbar 播放 USB 儲存裝置上的音樂檔案。
  - 若沒有 USB 裝置連接超過 20 分鐘，Soundbar 會自動關閉 (Auto Power Down)。

## 兼容的檔案格式類型清單

延長線	編碼	取樣率	位元率
*.mp3	MPEG1 Layer2	32kHz ~ 48kHz	32kbps ~ 320kbps
	MPEG1 Layer3	32kHz ~ 48kHz	32kbps ~ 320kbps
	MPEG2 Layer3	16kHz ~ 24kHz	8kbps ~ 160kbps
	MPEG2.5 Layer3	8kHz ~ 12kHz	8kbps ~ 160kbps
*.wma	WMA7/8/9	32kHz ~ 48kHz	32kbps ~ 320kbps
*.ogg	Vorbis	32kHz ~ 48kHz	45kbps ~ 500kbps
*.aac *.m4a	AAC-LC (MPEG2/MPEG4 僅限音訊)	32kHz ~ 48kHz	32kbps ~ 320kbps
*.wav	LPCM	32kHz ~ 192kHz	1024kbps ~ 9216kbps
*.flac	FLAC	32kHz ~ 192kHz	162kbps ~ 8100kbps
*.aiff	AIFF	32kHz ~ 192kHz	1024kbps ~ 9216kbps


- 若 USB 裝置上存儲了太多資料夾 (約 200 個) 和檔案 (約 2,000 個)，Soundbar 可能需要一定時間來存取和播放檔案。
- Soundbar 僅支援檔案系統為 FAT16 (~2GB)、FAT32 (~2TB) 或 NTFS (~2TB) 的 USB 裝置。

## 09 連接流動裝置

### 透過藍牙連接

透過藍牙連接流動裝置時，您可以欣賞立體聲，而無需因處理纜線而煩惱。

- 僅可同時連接一部電視或兩個藍牙裝置。



### 初始連接

1. 按下遙控器上的 **PAIR** 按鈕，以進入「BT PAIRING」模式。  
(或)
  - a. 按下上方面板的 **☞ (來源)** 按鈕，然後選擇「BT」。  
「BT」會在數秒內自動轉為「BT PAIRING」，若有連接記錄則會轉為「BT READY」。
  - b. 看到「BT READY」時，按住 Soundbar 上方面板上的 **☞ (來源)** 按鈕超過 5 秒，以顯示「BT PAIRING」。
2. 在裝置上，從顯示的清單中選擇「[AV] Samsung Soundbar B5-Series」。
  - Soundbar 連接至藍牙裝置後，[藍牙裝置名稱] → 「BT」會在前方螢幕上顯示。
3. 透過 Soundbar 播放藍牙連接裝置上的音樂檔案。



### 若裝置無法連接

- 如果先前連接的 Soundbar (例如「[AV] Samsung Soundbar B5-Series」) 在清單上出現，請將它刪除。
- 然後重複第 1 和 2 步。

### 注意

- 首次將 Soundbar 連接至流動裝置後，可使用「BT READY」模式重新連接。

## BT READY 和 BT PAIRING 有什麼不同？

- **BT READY**：在這個模式，您可以搜尋先前已連接的電視，或將先前已連接的流動裝置連接至 Soundbar。
- **BT PAIRING**：在這個模式，您可以將新裝置連接至 Soundbar。(按下遙控器上的  **PAIR** 按鈕，或在 Soundbar 處於「BT」模式時按住 Soundbar 上方面板的  (來源) 按鈕超過 5 秒。)

## 備註

- 如果系統在連接藍牙裝置時要求輸入 PIN 碼，請輸入 <0000>。
- 在藍牙連接模式下，若 Soundbar 和藍牙裝置相距超過 10 米，藍牙連接會中斷。
- 在待機狀態下，Soundbar 會在 20 分鐘後自動關閉。
- 在以下情況下，Soundbar 可能不會執行藍牙搜尋，或正確連接：
  - 若 Soundbar 附近的電場強烈。
  - 若數部藍牙裝置同時配對至 Soundbar。
  - 若藍牙裝置已關閉、不存在或發生故障。
- 電子裝置可能會導致無線電干擾。發放電磁波的裝置必須與 Soundbar 主設備保持遠距離，當中包括微波爐、無線 LAN 裝置等。
- Soundbar 支援 SBC 資料 (44.1kHz、48kHz)。
- 只連接支援 A2DP (AV) 功能的藍牙裝置。
- 您不可將 Soundbar 連接至只支援免提功能的藍牙裝置。
- 將 Soundbar 配對至藍牙裝置後，從裝置的掃描裝置清單選擇「[AV] Samsung Soundbar B5-Series」，Soundbar 便會自動切換至「BT」模式。
  - 只在 Soundbar 出現在藍牙裝置的配對裝置清單時可用。  
(藍牙裝置和 Soundbar 必須曾經配對最少一次。)
- 只有 Soundbar 顯示「BT READY」時，Soundbar 才會在藍牙裝置的搜尋裝置清單上出現。

## Bluetooth Power 開 (SOUND MODE)

若想將曾經配對過的藍牙裝置與 Soundbar 配對，則當 Bluetooth Power 開功能打開時，即使 Soundbar 為關閉狀態，Soundbar 也會自動開啟。

1. 當 Soundbar 開啟時，按住 **SOUND MODE** 按鈕 5 秒以上。
2. 「ON-BLUETOOTH POWER」出現在 Soundbar 的顯示螢幕上。

## 從 Soundbar 解除連接藍牙裝置

您可以從 Soundbar 解除連接藍牙裝置。如需指引，請參閱藍牙裝置的使用者手冊。

- Soundbar 將會解除連接。
- Soundbar 從藍牙裝置解除連接後，Soundbar 的顯示螢幕上會顯示「BT DISCONNECTED」。

## 從藍牙裝置解除連接 Soundbar

按下上方面板或遙控器上的  (來源) 按鈕，然後變更為「BT」以外的模式。

- 由於藍牙裝置必須接收 Soundbar 的回應，因此解除連接需要時間。(解除連接的時間可能有異，視乎藍牙裝置而定)
- Soundbar 從藍牙裝置解除連接後，Soundbar 的顯示螢幕上會顯示「BT DISCONNECTED」。

### 備註

- 在藍牙連接模式下，若 Soundbar 和藍牙裝置相距超過 10 米，藍牙連接會中斷。
- 在準備就緒狀態下，Soundbar 會在 20 分鐘後自動關閉。

## 更多有關藍牙的資訊

藍牙是讓支援藍牙的裝置在短距離之間互相無線連接的技術。

- 在以下情況，藍牙裝置可能會發出噪音或發生故障，視乎使用情況而定：
  - 您的身體部分接觸藍牙裝置的接收/傳輸系統或 Soundbar。
  - 裝置會受障礙物 (例如牆壁，角落或區域分隔物) 而引致的電磁變化影響。
  - 裝置暴露於頻帶相同的裝置的電磁干擾下，其中包括醫療設備、微波爐和無線 LAN。
- 將 Soundbar 與藍牙裝置靠近並配對。
- Soundbar 和藍牙裝置相隔愈遠，品質愈低。  
若距離超出藍牙操作範圍，連接便會中斷。
- 在接收較差的地方，藍牙連接可能無法正常運作。
- 只有裝置靠近時，藍牙連接才可正常運作。若藍牙裝置超出範圍，連接會自動中斷。即使範圍內，音質亦可能會因障礙物 (例如牆或門) 而下降。
- 此無線裝置可能會在運作期間引致電磁干擾。

## 藍牙多重連接


Soundbar 可同時連接兩個藍牙裝置。



1. 把最多兩個藍牙裝置連接至 Soundbar。(請參閱第 27 頁。)
2. 連接兩個裝置時，從其中一個已連接的藍牙裝置播放音樂。
3. 當 Bluetooth 裝置「B」開始播放裝置「A」正在播放的音樂時，裝置「B」開始播放音樂，而裝置「A」則自動停止/暫停播放。
4. 如果是 AVRCP V1.4 或更舊的版本，切換播放音樂的裝置時可能會花費更多時間。

## 藍牙多重配對

### 如何同時將多部裝置連接至 Soundbar

1. 開啟 Soundbar。
2. 只有在「BT」模式下，按住 Soundbar 上的  (來源) 按鈕超過 5 秒，Soundbar 便會進入「BT PAIRING」模式。然後在 Bluetooth 裝置上開啟 Bluetooth，並從可用裝置清單中選取 Soundbar，Soundbar 便會自動連接至 Bluetooth 裝置。
3. 使用同樣方法，便可以將第二部藍牙裝置連接至 Soundbar。  
如您需要連接第三部裝置，沒有播放聲音的已連接裝置將會解除藍牙連接，但仍會維持與 Soundbar 的配對。
4. 您可以使用同樣方法配對最多 8 部藍牙裝置，但只有最後連接的 2 部裝置才會同時連接至 Soundbar。

### 備註

- Soundbar 同一時間只可以連接 1 部 Samsung 電視和 2 部藍牙裝置。
- 有 Soundbar 接到 Samsung 電視的連接要求時，會與藍牙裝置解除連接。
- Soundbar 會預設為「ON-BT MULTI CONNECTION」，如要從另一種模式回復至非多重連接模式，請按住  PAIR 按鈕。遙控器處於待機模式超過 5 秒，螢幕便會顯示「OFF-BT MULTI CONNECTION」。

## 10 安裝牆壁安裝托架

## 牆壁安裝托架元件

### 安裝注意事項

- 只在垂直牆上安裝。
- 不要在高溫或潮濕的地方安裝。
- 確定牆壁可承受產品重量。否則，請強化牆壁或選擇另一個安裝位置。
- 購買或使用您牆壁類型（石膏板、鐵板、木材等）適合的固定螺絲或錨。可行的話，將支援螺絲固定在牆上的螺柱。
- 根據安裝 Soundbar 的牆壁的類型和厚度購買牆上的安裝螺絲。
  - 直徑：M5
  - 長度：建議 35 毫米或以上。
- 在牆上安裝 Soundbar 前，從設備將連接線連接至外部裝置。
- 確保設備已經關閉而且已從電源拔除，然後才著手安裝，否則可能會造成觸電。



牆壁安裝托架指示圖



螺絲固定器




螺絲




牆壁安裝托架

1. 將**牆壁安裝托架指示圖**貼在牆面。

- **牆壁安裝托架指示圖**必須為水平。
- 如果您在牆上安裝電視，Soundbar 應安裝在電視下方最少 5 厘米位置。




↑↓ 5 厘米或以上




2. 將**牆壁安裝指引圖**的**中央線**對齊電視的中心位置 (若將 Soundbar 安裝在電視的下方), 再用膠紙將**牆壁安裝指引圖**固定在牆上。

- 若非安裝於電視下方, 請將**中線**對準安裝位置的中心。




3. 用筆標記出鑽孔的位置, 然後移除**牆壁安裝指引圖**。




4. 用尺寸合適的鉗頭在各標記處鉗孔。
- 若標記與牆體上位置不符, 在插入固定螺釘前, 請確定您是否在孔中插入正確的螺釘。若使用螺釘, 請確保鉗孔足夠大可以插入螺釘。


5. 在每個**螺絲固定器**中插入一個螺釘 (未提供), 再將支架螺釘中的螺釘擰緊。




6. 使用 2 顆**螺釘**, 在 Soundbar 底部的正確方向安裝 2 顆**牆壁安裝托架**。



- 組裝時, 確定**牆壁安裝托架**的掛勾部分位於 Soundbar 的後方。




7. 將**牆壁安裝托架**懸掛在牆上的**螺絲固定器**上，即可透過**牆壁安裝托架**來安裝 Soundbar。




8. 向下拉動 Soundbar 如下所示，讓**牆壁安裝托架**安全擺放在**螺絲固定器**上。

- 將**螺絲固定器**插入**牆壁安裝托架**的寬 (底部) 部分，然後向下拉動**牆壁安裝托架**，讓**牆壁安裝托架**安全擺放在**螺絲固定器**上。



## 11 軟件更新

Samsung 可能會日後為 Soundbar 系統固件提供更新。




如有更新，可將包含固件更新的 USB 裝置連接至 Soundbar 的 USB 連接埠，以更新固件。如需更多有關下載更新檔案方法的資料，請前往 Samsung Electronics 網站

[www.samsung.com](http://www.samsung.com) → Support。

然後，選擇產品類型，或輸入 Soundbar 型號，選擇「軟件和應用程式」，然後選擇「下載」。請注意，選項名稱可能有所不同。

### 如何檢查韌體版本

- 關閉 Soundbar。
- 按住遙控器上的  (聲音控制) 按鈕大約 5 秒。
- 各個版本會按以下次序出現在 Soundbar 顯示屏上。

(軟件版本 → HDMI → Tx → Rx)

- Tx** : Soundbar 中的無線 Tx 模組。
- Rx** : 低音炮中的無線 Rx 模組。
- R2 版本顯示**
  - 無連接後置 R2---
  - 已連接後置 R2xxx

## 更新程序

**重要說明：**更新功能會清除所有使用者設定。我們建議您記下設定，以便您在更新後重設。請注意，更新固件亦會重設低音炮連接。

1. 將 USB 磁碟連接至電腦上的 USB 連接埠。

**重要說明：**確定 USB 磁碟內沒有音樂檔案。這可能會導致固件更新失敗。

2. 前往 (samsung.com) → 選擇「輸入型號」，然後輸入 Soundbar 的型號。選擇手冊並下載最新的軟件檔案。
3. 將下載的軟件儲存至 USB 記憶體，然後選擇「提取至這裡」以解壓縮資料夾。
4. 關閉 Soundbar，並將放有軟件更新的 USB 手指連接至 USB 插口。
5. 開啟 Soundbar 後，將來源模式切換為「USB」模式。「UPDATE」字樣會於 3 分鐘內出現，更新開始。完成更新時，Soundbar 會自動關閉再開啟。
6. 按住頂部面板的 **— + (音量)** 按鈕 5 秒。「INIT」會在螢幕上出現，而 Soundbar 會關閉。更新已經完成。
  - 本產品設有 DUAL BOOT 功能。若韌體更新失敗，您可以再次更新韌體。
7. 回復您 Soundbar 上的設定。

## 若「更新」沒有顯示

1. 關閉 Soundbar，將包含更新檔案的 USB 儲存裝置解除連接並重新連接至 Soundbar 的 USB 連接埠。
2. 拔除 Soundbar 的電源線並重新插入，然後開啟 Soundbar。

### 備註

- 若 Soundbar 支援的音訊檔案儲存在 USB 儲存裝置，更新韌體可能無法正常運作。
- 更新時，不要關閉電源或移除 USB 裝置。完成韌體更新後，主設備會自動關閉。
- 更新完成後，Soundbar 的使用者設定會初始化，以便您重設設定。我們建議您記下設定，以便在更新後輕鬆重設設定。請注意，更新韌體亦會重設低音炮連接。更新後，若低音炮連接沒有自動重新建立，請參閱第 16 頁。若軟件更新失敗，請檢查 USB 記憶體是否損毀。
- Mac OS 使用者應使用 MS-DOS (FAT) 作為 USB 格式。
- 可能無法透過 USB 更新，視乎 USB 儲存裝置製造商而定。

# 12 解決疑難

在尋求幫助前，請檢查以下事項。

## Soundbar 無法開啟。

- 檢查 Soundbar 的電源線有否正確插入插座。

## Soundbar 運作異常。

- 拔下電源插頭，然後重新連接。
- 重啟外部裝置，然後再試一次。
- 如果沒有訊號，Soundbar 會在一定時間後自動關閉。關閉電源。  
(請參閱第 7 頁)。

## 如果遙控器無法使用。

- 直接將遙控器指向 Soundbar。
- 更換新電池。

## Soundbar 聲音並無輸出。

- Soundbar 音量可能太低或開啟了靜音功能。調整音量。
- 如果連接了任何外置裝置 (STB、藍牙裝置、流動裝置等等)，請調整該外置裝置的音量。
- 關於電視的聲音輸出，請選擇 Soundbar。(Samsung 電視：首頁 (🏠) → 功能表 → 設定 (⚙️) → 所有設定 (⚙️) → 音效 → 音效輸出 → 選擇 Soundbar)
- 連接至 Soundbar 的連接線不得鬆脫。移除連接線並重新連接。
- 完全移除電源線、重新連接，並開啟電源。
- 初始化產品並重試。  
(請參閱第 34 頁)。

## 有源重低音音箱無法輸出任何聲音。

- 檢查低音炮後方的 LED 指示燈有否亮起藍色。若指示燈閃動藍色或轉為紅色，則重新連接 Soundbar 和低音炮。(請參閱第 17 頁)。
- 如果 Soundbar 和低音炮放置了阻礙物，可能會發生問題。將裝置移離阻礙物。
- 若附近設有傳送無線電頻訊號的裝置，可能會影響連接。請將揚聲器遠離這些裝置。
- 移除和重新連接電源插座。

## 低音炮音量過低。

- 您播放內容的原來音量可能過低。嘗試調校低音炮的音量。  
(請參閱第 12 頁)。
- 將低音炮揚聲器靠近您。

## 如果電視並非以 HDMI TO TV (ARC) 連接。

- 檢查 HDMI 纜線有否正確連接至 ARC 端子。(請參閱第 19 頁)。
- 可能會因已連接的外置裝置 (機頂盒、遊戲主機等等) 而無法進行連接。直接連接 Soundbar。
- 電視的 HDMI-CEC 可能未啟用。打開電視功能表的 CEC。(Samsung 電視：首頁 (🏠) → 功能表 → 設定 (⚙️) → 所有設定 (⚙️) → 連線 → 外置裝置管理員 → Anynet+ (HDMI-CEC)開)

### 連接至電視輸入 HDMI TO TV (ARC) 模式時，裝置不會發出聲音。

- 您的裝置無法播放輸入訊號。將電視的音訊輸出變更為 PCM 或 Dolby Digital。(若使用三星電視：首頁 (🏠) → 功能表 → 設定 (⚙️) → 所有設定 (⚙️) → 音效 → 專家設定 → 數碼輸出音頻格式)

### Soundbar 無法透過 Bluetooth 進行連接。

- 連接新裝置時，切換至「BT PAIRING」，以進行連接。(按下遙控器上的 **PAIR** 按鈕，或按下機身的 **☑️ (來源)** 按鈕最少 5 秒。)
- 如果 Soundbar 連接至其他裝置，請先解除連接裝置，以切換至裝置。
- 從可連接裝置清單移除藍牙揚聲器清單後重新連接。(Samsung 電視：首頁 (🏠) → 功能表 → 設定 (⚙️) → 所有設定 (⚙️) → 音效 → 音效輸出 → 藍牙揚聲器列表)
- 自動電視連接可能已停用。Soundbar 處於「BT READY」時，按住 Soundbar 遙控器上的 **左** 按鈕 5 秒，以選擇 **ON-TV CONNECT**。如果您看到 **OFF-TV CONNECT**，再次按住 **左** 按鈕 5 秒以切換選擇。
- 移除和重新連接電源插座，然後重試。
- 初始化產品並重試。(請參閱第 34 頁)。

### 透過 Bluetooth 連接時沒有聲音。

- 如果透過 Bluetooth 連接的裝置距離 Soundbar 太遠，便可能會沒有聲音。把裝置移近 Soundbar。
- 如果您身體的某部位接觸到 Bluetooth 收發器，或者產品安裝於金屬傢俱上，便可能會沒有聲音。  
請檢查安裝環境和使用條件。

### Bluetooth 多重連接無法運作。

- 連接電視和 Soundbar 後，Bluetooth 多重連接無法正常運作。從電視解除 Soundbar 的連接然後再試一次。
- 檢查是否已開啟 Bluetooth 多重連接設定。(請參閱「**Soundbar 無法透過 Bluetooth 進行連接。**」部分。)
- 解除連接正在播放內容的裝置，與要連接的裝置配對，然後再重新連接之前的裝置。
- 如果正確連接後仍然聽不到聲音，請參閱「**透過 Bluetooth 連接時沒有聲音。**」部分。

### Soundbar 無法隨著電視自動開啟。

- 看電視時關閉 Soundbar，與電視之間的電源同步便會停止。請先把電視關掉。



Manufactured under license from Dolby Laboratories. Dolby, Dolby Audio and the double-D symbol are trademarks of Dolby Laboratories Licensing Corporation.



For DTS patents, see <http://patents.dts.com>. Manufactured under license from DTS Licensing Limited. DTS, the Symbol, DTS in combination with the Symbol, DTS and the Symbol together, Virtual:X, the DTS Virtual:X logo, and DTS 2.0 Channel are registered trademarks or trademarks of DTS, Inc. in the United States and/or other countries. © DTS, Inc. All Rights Reserved.



The terms HDMI and HDMI High-Definition Multimedia Interface, and the HDMI Logo are trademarks or registered trademarks of HDMI Licensing Administrator, Inc. in the United States and other countries.



The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Samsung Electronics Co., Ltd. is under license. Other trademarks and trade names are those of their respective owners.



## [ENERGY STAR]

### ENERGY STAR qualified model only

- Your Samsung product is ENERGY STAR qualified in its factory default setting. Change to certain features, settings and functionality in this product can change the power consumption, possibly beyond the limits required for ENERGY STAR qualification.
- Environmental Protection Agency and Department of Energy. ENERGY STAR is a joint program of the Government agencies, designed to promote energy efficient products and practices.

Refer to [www.energystar.gov](http://www.energystar.gov) for more information of the ENERGY STAR Program.

### ENERGY STAR qualified model only (Applicable to Thin Client models only)

As an ENERGY STAR® Partner, SAMSUNG has determined that this product meets the ENERGY STAR® guidelines for energy efficiency.

- The ENERGY STAR Program has been to reduced greenhouse gas emissions and save energy through voluntary labeling.
- Power management setting of this product have been enabled by default, and have various timing setting from 1 minutes to 5 hours.
- The product can wake with a button press on the chassis from sleep mode.

### ENERGY STAR qualified model only (The other models)

- As an ENERGY STAR Partner, Samsung has determined that this product or product models meets the ENERGY STAR guideline for energy efficiency.

## 14 開源軟件許可聲明

如要提出有關開放源問題的查詢和要求，請  
聯絡三星開放源

(<http://opensource.samsung.com>)

## 15 有關維修的重要說明

本使用說明書中的圖片和圖解僅供參考，可能與實際的產品外觀有所不同。

# 16 規格和指南

## 規格

型號名稱	HW-B550
USB	5V/0.5A
重量	2.1 千克
尺寸 (寬 x 高 x 厚)	860.0 x 59.4 x 75.0 毫米
工作溫度範圍	+5°C 到 +35°C
工作濕度範圍	10 % ~ 75 %
擴音器 額定輸出功率	160W (40W x 4)
支援的播放格式 (DTS 2.0 和 DTS Virtual:X 聲音以 DTS 格式播放。)	LPCM 2ch、Dolby Audio™ (支援 Dolby® Digital)、DTS、DTS Virtual:X

低音炮名稱	PS-WB65D
重量	5.1 千克
尺寸 (寬 x 高 x 厚)	184.0 x 346.0 x 295.0 毫米
擴音器 額定輸出功率	250W

## 備註

- Samsung Electronics Co., Ltd 保留隨時變更規格的權利，恕不另行通知。
- 重量和尺寸為估計值。

© 2022 Samsung Electronics Co., Ltd. All rights reserved.

## Contact SAMSUNG WORLD WIDE

If you have any questions or comments relating to Samsung products, please contact the SAMSUNG customer care Centre.

Country / Area	Samsung Service Centre ☎	Web Site
■ Asia Pacific		
CHINA	400-810-5858	<a href="http://www.samsung.com/cn/support">www.samsung.com/cn/support</a>
TAIWAN	0800-329-999 0809-00-5237 (B2B / Dealer)	<a href="http://www.samsung.com/tw/support">www.samsung.com/tw/support</a>
HONG KONG	3698 4698 (All Product) 3698 4688 (B2B) 3698 4633 (eStore) 2121 9088 (Samsung pay)	<a href="http://www.samsung.com/hk/support">www.samsung.com/hk/support</a> (Chinese) <a href="http://www.samsung.com/hk_en/support">www.samsung.com/hk_en/support</a> (English)
MACAU	0800 333	
SINGAPORE	1800 7267864   1800-SAMSUNG	<a href="http://www.samsung.com/sg/support">www.samsung.com/sg/support</a>
AUSTRALIA	1300 362 603	<a href="http://www.samsung.com/au/support">www.samsung.com/au/support</a>
NEW ZEALAND	0800 726 786	<a href="http://www.samsung.com/nz/support">www.samsung.com/nz/support</a>
VIETNAM	Toll free numbers: 1800 588 889 (All Product) Hotline: (028)73056888	<a href="http://www.samsung.com/vn/support">www.samsung.com/vn/support</a>
THAILAND	1800-29-3232 (Toll free for all product)	<a href="http://www.samsung.com/th/support">www.samsung.com/th/support</a>
MYANMAR	+95-1-2399-888	<a href="http://www.samsung.com/mm/support">www.samsung.com/mm/support</a>
CAMBODIA	1800-20-3232 (Toll free)	<a href="http://www.samsung.com/th/support">www.samsung.com/th/support</a>
LAOS	+856-214-17333	
MALAYSIA	1800-88-9999 +603-7713 7420 (Overseas contact)	<a href="http://www.samsung.com/my/support">www.samsung.com/my/support</a>
INDONESIA	021-5699-7777 0800-112-8888 (All Product, Toll Free) 0800-112-7777 (All Product, Toll Free)	<a href="http://www.samsung.com/id/support">www.samsung.com/id/support</a>
PHILIPPINES	Dedicated Hotline for Mobile Phones: #GALAXY (just dial #425299) All Products: 1-800-10-7267864 [PLDT - Toll Free] 1-800-8-7267864 [Globe - Toll Free] 84222111 [Landline]	<a href="http://www.samsung.com/ph/support">www.samsung.com/ph/support</a>
INDIA	1800 40 SAMSUNG (1800 40 7267864) (Toll-Free) 1800 5 SAMSUNG (1800 5 7267864) (Toll-Free)	<a href="http://www.samsung.com/in/support">www.samsung.com/in/support</a>
NEPAL	16600172667 (Toll Free for NTC Only) 9801572667 (Toll Free for Ncell users)	<a href="http://www.samsung.com/in/support">www.samsung.com/in/support</a>
BANGLADESH	08000-300-300 (Toll free) 09612-300-300	<a href="http://www.samsung.com/bd/support">www.samsung.com/bd/support</a>
SRI LANKA	011 SAMSUNG (011 7267864)	<a href="http://www.samsung.com/in/support">www.samsung.com/in/support</a>