

## Stairnosings Installation Guide

1. Ensure the stairs are flat (use a repair mortar to make good any irregularities)
2. Remove any debris and make sure the stairs are dry and clean.
3. Check the nosing for a good fit by placing on the correct stair, then mark through the drill holes, the fitter must ensure the nosing is pushed hard against the riser.
4. Remove the nosing.
5. For concrete or stone steps, drill and plug.
6. Apply cartridge adhesive to the underside of the nosing and re-position on the step. For Heavy Duty Gripper Adhesive, remove and let it stand for approximately 15 minutes than refit the nosing to help reduce the curing time. For Fast Setting Gripper Adhesive, press the nosing into the adhesive immediately and allow to set.
7. Screw down the nosing firmly.
8. Apply the insert plug to hide the screw.