

Mercedes Sprinter / VW Crafter /MAN TGE Wheel carrier instructions

The first thing to do is put the wheel holder in place.

You can put the screws (red arrow) without the nuts and mark the hole on the panel (yellow arrow)

The support is removed and the hole is made (10mm)



If your door hinges are 180 degrees, all you have to do is to screw it at his place, putting the internal round reinforcement.



If they are 270 degrees, first you have to cut the guide rod, as it is marked with red lines in the pictures and fix the wheel carrier with the door opened.

Take care to close the door, because the first time it may need some adjustment not to break the rear light