

Earth spike copper clad



The copper clad earth spike or stake is used to earth the electric fence system. A minimum of 3 earth spikes must be knock into the ground near the electric fence at a minimum of 1.5 m apart. Connect these earth spikes to the energizer or the fence using the high tension insulated cable (HT). In areas where earthing conditions are bad you may be required to add a few more earth spikes/stakes along the fence line and connect these back to the energiser.

Features:

- Copper clad nuts and washers
- Available in both 1.0m and 1.2m lengths
- The double nut and washer allow for a good electrical connection with the HT cables

Specifications:

Finish: Copper clad

Lengths: 10mm x 1.0m

10mm x 1.2m

<https://www.nemtek.co.za/homesecurity/General-Accessories/earth-spike-copper-clad.aspx>

Stock Code	Name	Description
EA-EAN	Earth spike copper clad	Earth Spike - Copper - 1m (nut/washer)
EA-EAN/L	Earth spike copper clad	Earth Spike - Copper - 1.2m (nut/washer)