

אִיטֵק ITEC

INPUT

00 01 02 03 04 05 06 07 08 09 10 11


ON
OFF
ON

INPUT COM

MAIN POWER

FUSE

POWER



0

פוטנצימטר

ALALOG INPUT

+24 V

PLC

HMI

OUTPUT

00 01 02 03 04 05 06 07

OUTPUT COM

בִּקְר מֵתוֹכָנֹת

