



foldable bluetooth keyboard

## User Guide

(VER: A)


### Package Contents

- foldable bluetooth keyboard: 1 pcs
- Micro usb charging cable line: 1 pcs
- User guide: 1 pcs


please read the user guide carefully and correctly use it



### 1-Exterior view



### 2-Bluetooth pairing



- [1] Switch the power switch to "ON", the bluetooth LED light up, then press the combination keys "FN+C" to enter the bluetooth pairing mode.
- [2] In your computer or phone's "Setting", turn on bluetooth, searching for bluetooth devices. When the "Bluetooth Keyboard" is founded, click it into pairing.
- [3] Enter the corresponding password on the keyboard according to the prompts of the computer device, then click "Enter" key to confirm and complete the connection. You can start typing comfortably now.

### 3-Status Display Led

- [1] Connect : Open the power switch, blue lights up, press the [fn+C]. blue light twinkles.
- [2] Charging : Indicator light will be on red, after fully charging, the light crush out. Low Voltage Indication : When the voltage is below 3.3 V, red light twinkles.
- [3] Remarks: In order to prolong the life span of the battery, when you do not use the keyboard for a long time, please switch off the power.

### 4- Specification of keyboard

- Bluetooth version: 3.0
- Open size: 315\*91\*6.1mm
- Fold size: 161\*91\*12.5mm
- Keys layout: QWERTY US
- Number of keys: 64 PCS
- Power supply: 140mAh
- Working voltage: 3.3V-4.2V
- Charging voltage: DC=5V(500mA)
- Continuous use: Up to 40H
- Standby time: Up to 60Days
- Charge time: 2H

#### Troubleshooting

Please contact the after-sales service.

#### Copyright

It is forbidden to reproduce any part of this quick start guide without the permission of seller.

#### Safety instructions

Do not open or repair this device, Do not use the device in a damp environment. Clean the device with a dry cloth.


#### Warranty

The device is provided with one-year limited hardware warranty from the purchase day.


### 5-FAQ

- [1] The tablet PC can't connect the BT keyboard ?
- [2] At first check the BT keyboard is into match code state, then open the table PC Bluetooth searching.
- [3] Checking the BT keyboard Battery is enough, the battery low is also lead to can't connect, you need charge.
- [4] The keyboard indication light always flashing when use?
- [5] Keyboard indication always flashing when use, is means the battery will be no power , please charge the power as soon as possible.
- [6] The device shows that the bluetooth keyboard is disconnected
- [7] The BT keyboard will into dormant to save the battery after some time later no use; press any key the BT keyboard will be awaken and working.

### 1- Vista Exterior



### 2- Enlace Bluetooth



Iniciar Enlace Bluetooth

- [1] Encienda el dispositivo y el indicador se encendera. Después oprima al mismo tiempo las teclas "Fn y C" para Iniciar el enlace Bluetooth.
- [2] En el dispositivo que vaya a enlazar vaya a Configuración, encienda la función Bluetooth y comience a buscar dispositivos para enlazar. Cuando aparezca "Bluetooth Keyboard" selecciónelo.
- [3] Si su dispositivo indica un PIN o clave de conexión, ingrese ese mismo número al teclado y oprima Enter. En caso de que NO indique un PIN/Clave en específico ingrese el código standard "0000" (cuatro ceros).

### 3- Luces Indicadoras

- [1] Estado Conectando: Se enciende luz indicadora y parpadea al encender y oprimir teclas Fn+C.
- [2] Estado Cargando: Luz indicadora se enciende en color rojo. Cuando este cargado totalmente la luz se apagará. En caso de bajo nivel de pila, la luz indicadora roja parpadea.
- [3] Se recomienda apagar siempre el teclado cuando NO este en use.

### 4- Especificaciones

- Version Bluetooth: 3.0
- Medida Abierto: 31x91x6mm
- Medida Cerrado: 16x91x12.5mm
- Tipo de Teclado: QWERTY US
- No. Teclas: 64
- Capacidad Pila: 140mAh
- Consumo de Energía: 3.3V -4.2V
- Voltaje de Carga: DC = 5V (500mAh)
- Duración Pila: Hasta 40 Horas en Uso
- Duración de pila en standby: 60 Dias
- Tiempo de Carga: 2 Horas

#### NOTAS:

En caso de problemas con el teclado, contactarnos .

NO use el teclado en ambientes muy húmedos, no derrame líquidos, limpie solo con un paño seco.

Garantía por defectos de fábrica, no por golpes, daños o mal uso por parte del usuario.

### 5- Preguntas Frecuentes

- [1] No se enlaza mi teclado.
- [2] Revise que el teclado este en MODO de ELACE (teclas Fn+C y luz led parpadeando).
- [3] Revise si la pila esta cargada o si indica bajo nivel de energía.
- [4] Si la luz roja parpadea, la pila se agotara pronto y dejara de funcionar. Cargue la pila a la brevedad.
- [5] El teclado indica que el enlace Bluetooth esta desactivado.
- [6] El teclado pone en pausa el enlace Bluetooth para ahorrar pila. Simplemente oprima cualquier tecla para reanudar el enlace.

## 6-Function Keys

fn +  Switch to iOS			fn +  Switch to Android			fn +  Switch to Win					
fn+	=	function	fn+	=	function	fn+Shift+	=	function	fn+	=	function
		Home			Desk top			Home page			ESC
		Serch			Serch			Serch			f 1
		Selcet all			Selcet all			Selcet all			f 2
		Copy			Copy			Copy			f 3
		Paste			Paste			Paste			f 4
		Cut			Cut			Cut			f 5
		Prev			Prev			Prev			f 6
		Break			Break			Break			f 7
		Next			Next			Next			f 8
		Mute			Mute			Mute			f 9
		Volume -			Volume -			Volume -			f 10
		Volume +			Volume +			Volume +			f 11
		Lock screen			Lock screen			Lock screen			f 12
		Delete			Delete			Delete			(Backspace)

Right + = \ ; Right + = @ . . . . .

Right + = C (in iOS)

## 7-TouchPad function

1-Finger	2-Finger	3-Finger	4-Finger
Left Click Double Click	Right Click	Invoke Cortana	Invoke Action Center
Move Cursor	Scroll/Pan	Multitasking Gestures	
Type+Slide	Pinch/Zoom		

### Notice:

For systematic reasons,  
Touchpad is not compatible with iOS products

## 8-Keyboard Maintenance

- Please keep the keyboard away from liquid or humid environment, saunas, swimming pool, steam room and don't let the keyboard get wet in the rain.
- Please don't expose the keyboard at too high or too low temperature condition.
- Please don't put keyboard under sun for a long time.
- Please don't put keyboard close to the flame, such as cooking stoves, candles or fireplace.
- Avoid sharp objects scratching products, timely to recharge products to ensure the normal use.

## 6- Funciones

fn +  Switch a iOS			fn +  Switch a Android			fn +  Switch a Win					
fn+	=	funcion	fn+	=	funcion	fn+Shift+	=	funcion	fn+	=	funcion
		Home			Desk top			Home page			ESC
		Serch						Serch			f 1
		Selcet all						Selcet all			f 2
		Copy			Copy			Copy			f 3
		Paste			Paste			Paste			f 4
		Cut			Cut			Cut			f 5
		Prev			Prev			Prev			f 6
		Break			Break			Break			f 7
		Next			Next			Next			f 8
		Mute			Mute			Mute			f 9
		Volume -			Volume -			Volume -			f 10
		Volume +			Volume +			Volume +			f 11
		Lock screen			Lock screen			Lock screen			f 12
		Delete			Delete			Delete			(Backspace)

del lado derecho + = \ del lado derecho + = @ . . . . .

del lado derecho + = C (en iOS)

## 7- Funciones Pad

1- Dedo	2- Dedos	3- Dedos	4- Dedos
Click izquierdo	Click derecho	Llamar a Cortana	Llamar al centro de acciones
Mover cursor	Scroll/ Paneo	Multitarea	
Marca/ Desliza	Zoom/ Reducir		

### NOTAS:

Por razones sistematicas, las funciones del touchpad no son compatibles con productos con sistema iOS.

## 8- Mantenimiento del Teclado

- Mantenga alejado de fuentes de humedad como piscinas, saunas, vapores, regaderas, baños o cerca de líquidos que pudieran ser derramados sobre el teclado.
- No exponga el teclado a temperaturas extremas de calor o frio.
- No coloque el teclado directo sobre el rayo del sol por periodos prolongados de tiempo.
- Evite colocar el teclado cerca de fuentes de fuego o calor como estufas, velas, fogatas, etc.
- Evite cortar o perforar el teclado con objetos filosos.

Cargue la pila periodicamente.