

## **HMW-460 T5**

**INDUSTRIAL RANGE Powered by MTU** 



| SERVICE                  |         | PRP     | ESP         |  |
|--------------------------|---------|---------|-------------|--|
| POWER                    | kVA     | 460     | 508         |  |
| POWER                    | kW      | 368     | 406         |  |
| RATED SPEED              | r.p.m.  | 1.!     | 500         |  |
| MAIN VOLTAGE             | V       | 400     | /230        |  |
| AVAILABLE VOLTAGES       | V       | 200/115 | · 230 V (t) |  |
| RATED AT POWER<br>FACTOR | Cos Phi | 0       | ,8          |  |



#### INDUSTRIAL RANGE

HIMOINSA Company with quality certification ISO 9001

HIMOINSA gensets are compliant with EC mark which includes the following

- 2006/42/CE Machinery safety.
   2014/30/UE Electromagnetic compatibility.
   2014/30/UE electrical equipment designed for use within certain voltage limits
   2000/14/EC Sound Power level. Noise emissions outdoor equipment. (amended by
- 2005/88/EC)

   97/68/EC Emissions of gaseous and particulate pollutants.

   EN 12100, EN 13857, EN 60204

Ambient conditions of reference according to ISO 8528-1:2018 normative: 1000 mbar, 25°C, 30% relative humidity.

Prime Power (PRP):
According to ISO 8528-1:2018, Prime power is the maximum power which a generating set is capable of delivering continuously whilst supplying a variable electrical load when operated for an unlimited number of hours per year under the agreed operating conditions with the maintenance intervals and procedures being carried out as prescribed by the manufacturer. The permissible average power output (Ppp) over 24 h of operation shall not exceed 70 % of the PRP.

Emergency Standby Power (ESP):
According to ISO 8528-1:2018, Emergency standby power is the maximum power available during a variable electrical power sequence, under the stated operating conditions, for which a generating set is capable of delivering in the event of a utility power outage or under test conditions for up to 200 h of operation per year with the maintenance intervals and procedures being carried out as prescribed by the manufacturers. The permissible average power output over 24 h of operation shall not exceed 70 % of the ESP

Continuous Power (COP): According to Standard ISO 8528-1:2018, this is the maximum power available for continuous loads for unlimited running hours a year between the maintenance times recommended by the manufacturer under the environmental conditions established by the same.

 $^{\circ}\text{Class G2}^{\circ}$  performance according to the load impact test according to ISO 8528-5:2018

HIMOINSA HEADQUARTERS: Fábrica: Ctra. Murcia - San Javier, Km. 23,6 | 30730 SAN JAVIER (Murcia) Spain Tel.+34 968 19 11 28 Fax +34 968 19 12 17 Fax +34 968 19 04 20 | info@himoinsa.com | www.himoinsa.com | www.himoinsa.com

Manufacture facilities: SPAIN • FRANCE • INDIA • CHINA • USA • BRAZIL • ARGENTINA

Subsidiaries:
PORTUGAL | POLAND | GERMANY | UK | SINGAPORE | UAE | PANAMA |
DOMINICAN REPUBLIC | ARGENTINA | ANGOLA | SOUTH AFRICA



#### STANDARD SOUNDPROOFING





WATER-COOLED



THREE PHASE



50 HZ



STAGE 3A



DIESEL

Himoinsa has the right to modify any feature without prior notice.

Weights and dimensions based on standard products. Illustrations may include optional equipment.

Technical data described in this catalogue correspond to the available information at the moment of printing.

The illustrations and images are indicative and may not coincide in their entirety with the product.

Industrial design under patent.









## Engine Specifications | 1.500 r.p.m.

| Rated Engine Output (PRP) kW 392 Rated Engine Output (ESP) kW 433  Manufacturer MTU  Model 10V1600G10F  Engine Type 4-stroke diesel  Injection Type Direct  Aspiration Type Turbocharged and after-cooled  Number of cylinders and arrangement 10-V  Bore and Stroke mm 122 x 150  Displacement L 17,5  Cooling System Coolant  Lube Oil Specifications S10 W40  Compression Ratio 17,5  |                           |    |                 |
|--|---------------------------|----|-----------------|
| ManufacturerMTUModel10V1600G10FEngine Type4-stroke dieselInjection TypeDirectAspiration TypeTurbocharged and after-cooledNumber of cylinders and arrangement10-VBore and Strokemm122 x 150DisplacementL17,5Cooling SystemCoolantLube Oil Specifications\$10 W40  | Rated Engine Output (PRP) | kW | 392             |
| Model10V1600G10FEngine Type4-stroke dieselInjection TypeDirectAspiration TypeTurbocharged and after-cooledNumber of cylinders and arrangement10-VBore and Strokemm122 x 150DisplacementL17,5Cooling SystemCoolantLube Oil Specifications\$10 W40   | Rated Engine Output (ESP) | kW | 433             |
| Engine Type  Injection Type  Direct  Aspiration Type  Turbocharged and after-cooled  Number of cylinders and arrangement  Bore and Stroke  Displacement  L  17,5  Cooling System  Coolant  Lube Oil Specifications  A-stroke diesel  1urbocharged and after-cooled  10-V  11-V  11-V | Manufacturer              |    | MTU             |
| Injection Type  Aspiration Type  Aspiration Type  Number of cylinders and arrangement  Bore and Stroke  Displacement  L  17,5  Cooling System  Coolant  Lube Oil Specifications  Direct  Turbocharged and after-cooled  10-V  11-V  11-V  122 x 150  Coolant  S10 W40  | Model                     |    | 10V1600G10F     |
| Aspiration Type  Turbocharged and after-cooled  Number of cylinders and arrangement  Bore and Stroke  mm  122 x 150  Displacement  L  17,5  Cooling System  Coolant  Lube Oil Specifications  S10 W40  | Engine Type               |    | 4-stroke diesel |
| Number of cylinders and arrangement 10-V  Bore and Stroke mm 122 x 150  Displacement L 17,5  Cooling System Coolant  Lube Oil Specifications S10 W40   | Injection Type            |    | Direct          |
| Bore and Stroke mm 122 x 150  Displacement L 17,5  Cooling System Coolant  Lube Oil Specifications S10 W40   | Aspiration Type           |    |                 |
| Displacement L 17,5  Cooling System Coolant  Lube Oil Specifications S10 W40   |                           |    | 10-V            |
| Cooling System Coolant Lube Oil Specifications S10 W40   | Bore and Stroke           | mm | 122 x 150       |
| Lube Oil Specifications S10 W40  | Displacement              | L  | 17,5            |
|  | Cooling System            |    | Coolant         |
| Compression Ratio 17,5   | Lube Oil Specifications   |    | S10 W40         |
|  | Compression Ratio         |    | 17,5            |

| Lube oil consumption with full load         |      | 0,5 % of fuel consumption |
|---|------|---------------------------|
| Total oil capacity including tubes, filters | L    | 60,5                      |
| Total coolant capacity                      | L    | 94                        |
| Governor                                    | Type | Electrical                |
| Air Filter                                  | Type | Dry                       |
| Inner diameter exhaust pipe                 | mm   | 106                       |
|   |      |                           |



- Diesel engine
- 4-stroke cycle
- 24V electrical system
- Water separator filter (visible level)
- Dry air filter
- Radiator with pusher fan
- Radiator water level sensor
- HTW sender

- LOP sender
- Electronic governor
- Hot parts protection
- Moving parts protection



## Generator Specifications | MECC ALTE

| Manufacturer               |       | MECC ALTE       |
|----------------------------|-------|-----------------|
| Model                      |       | ECO40 3S/4 B    |
| Poles                      | No.   | 4               |
| Connection type (standard) |       | Star - Parallel |
| Mounting type              |       | S-1 14"         |
| Insulation                 | Class | H class         |

| IEC-34-5)         | IP23                           |
|-------------------|--------------------------------|
| Exciter system    | Self-excited,<br>brushless     |
| Voltage regulator | A.V.R. (Electronic)            |
| Bracket type      | Single bearing                 |
| Coupling system   | Flexible disc                  |
| Coating type      | Standard (Vacuum impregnation) |
|                   |                                |



- Self-excited and self-regulated
- IP23 protection
- H class insulation








#### **WEIGHT AND DIMENSIONS**

|  |       | Standard Version | High Capacity version |
|--|-------|------------------|-----------------------|
| Length (L)                               | mm    | 4500             | 4500                  |
| Height (H)                               | mm    | 2340             | 2740                  |
| Width (W)                                | mm    | 1800             | 1800                  |
| Maximum shipping volume                  | m³    | 18,95            | 22,19                 |
| Weight with liquids in radiator and sump | Kg    | 5582             | 6193                  |
| Fuel tank capacity                       | L     | 740              | 2000                  |
| Autonomy (70% PRP)                       | Hours | 10               | 27                    |
| Autonomy (100% PRP)                      | Hours | 7                | 20                    |
|  |       | Steel tank       | Steel tank            |



#### **SOUND PRESSURE**

| Sound pressure level | dB(A)@7m | $69 \pm 2,4$ |  |
|----------------------|----------|--------------|--|
|----------------------|----------|--------------|--|

#### **APPLICATION DATA**

#### **EXHAUST SYSTEM**

| Maximum exhaust temperature             | °C     | 500  |
|---|--------|------|
| Exhaust Gas Flow                        | m³/min | 93,6 |
| Maximum allowed back pressure           | mbar   | 150  |
| Exhaust Flange Size (external diameter) | mm     | 160  |

#### **NECESSARY AMOUNT OF AIR**

| Intake air flow         | m³/h | 2052 |
|-------------------------|------|------|
| Cooling Air Flow        | m³/s | 10,9 |
| Alternator fan air flow | m³/s | 0,9  |

#### **FUEL CONSUMPTION**

| Fuel Consumption ESP      | l/h | 108,87 |
|---------------------------|-----|--------|
| Fuel Consumption 100% PRP | l/h | 101,75 |
| Fuel Consumption 70 % PRP | l/h | 75,25  |
| Fuel Consumption 50 % PRP | l/h | 55,37  |

#### **FUEL SYSTEM**

| Fuel Oil Specifications    |   | Diesel |
|----------------------------|---|--------|
| Fuel Tank                  | L | 740    |
| Other fuel tank capacities | L | 2.000  |

#### STARTING SYSTEM

| Starting power          | kW  | 8      |
|-------------------------|-----|--------|
| Starting power          | CV  | 10,88  |
| Recommended battery     | Ah  | 75 x 2 |
| Auxiliary Voltage       | Vdc | 24     |
| Starter current peak    | А   | 800    |
| Nominal starter current | Α   | 250    |



Soundproofed version





- Steel chassis
- Anti-vibration shock absorbers
- Chassis with integrated fuel tank
- Fuel level gauge
- External emergency stop switch
- Bodywork made from high quality steel plate
- High mechanical strength
- Low noise emissions level

- Soundproofing provided by high-density volcanic rock wool
- Epoxy polyester powder coating
- Full access for maintenance (water, oil and filters, no need to remove the canopy)
- Reinforced lifting hooks for crane hoisting
- Watertight chassis (acts as a double barrier against liquid retention)
- Fuel tank drain plug
- Chassis drain plug
- Chassis ready for future mobile kit installation

- Steel residential silencer -35db(A) attenuation.
- Oil sump extraction kit
- Versatility to assemble a high capacity chassis with a metallic fuel tank
- IP Protection according to ISO 8528-13:2016
- 3 way valve for external fuel supply (available in 1/2" and 3/8" fittings) (Opcional).
- Fuel transfer pump (Opcional).





# FEATURES OF THE CONTROL UNITS

|             |                                    | CEM 7 | CEA 7 | CEC 7 | CEM7 + CEC7 |
|-------------|------------------------------------|-------|-------|-------|-------------|
|             | Voltage between phases             | •     | •     | •     | •           |
|             | Voltage between neutral and phase  | •     | •     | •     | •           |
|             | Current intensities                | •     | •     | •     | •           |
| i.<br>E     | Frequency                          | •     | •     | •     | •           |
| Readin      | Apparent power (Kva)               | •     | •     | •     | •           |
| <u>.</u>    | Active power (Kw)                  | •     | •     | •     | •           |
| era,        | Reactive power (kVAr)              | •     | •     | •     | •           |
| ē           | Power factor                       | •     | •     | •     | •           |
|             | Voltage between phases             |       | •     | •     | •           |
|             | Voltage between phases and neutral |       | •     | •     | •           |
|             | Current intensities                |       | •     | •     | •           |
|             | Frequency                          |       | •     | •     | •           |
| ī.<br>g     | Apparent power                     |       | •     |       |             |
| Readings    | Active power                       |       | •     |       |             |
| Ø           | Reactive power                     |       | •     |       |             |
| Z           | Power factor                       |       | •     |       |             |
|             | Coolant temperature                | •     | •     |       | •           |
| ø           | Oil pressure                       | •     | •     |       | •           |
| Readings    | Fuel level (%)                     | •     | •     |       | •           |
| Bea         | Battery voltage                    | •     | •     |       | •           |
| ä           | R.P.M.                             | •     | •     |       | •           |
| Engin       | Battery charge alternator voltage  | •     | •     |       | •           |
|             | High water temperature             | •     | •     |       | •           |
|             | High water temperature by sensor   | •     | •     |       | •           |
|             | Low water temperature by sensor    | •     | •     |       | •           |
|             | Low oil pressure                   | •     | •     |       | •           |
|             | Low oil pressure by sensor         | •     | •     |       | •           |
|             | Low water level                    | •     | •     |       | •           |
|             | Unexpected shutdown                | •     | •     |       | •           |
|             | Fuel storage                       | •     | •     |       | •           |
|             | Fuel storage by sensor             | •     | •     |       | •           |
|             | Stop failure                       | •     | •     |       | •           |
|             | Battery voltage failure            | •     | •     |       | •           |
| Protections | Battery charge alternator failure  | •     | •     |       | •           |
| tect        | Overspeed                          | •     | •     |       | •           |
|             | Underspeed                         | •     | •     |       | •           |
| Engine      | Start failure                      | •     | •     |       | •           |
| Ē           | Emergency stop                     | •     | •     | •     | •           |

Standard

Optional







|                       |   | CEM 7                                 | CEA 7                                 | CEC 7 | CEM7 + CEC7                           |
|-----------------------|---|---------------------------------------|---------------------------------------|-------|---------------------------------------|
|                       | High frequency  | GEIT /                                | •                                     | •     | •                                     |
|                       | Low frequency   | •                                     | •                                     | •     | •                                     |
|                       | High voltage  | •                                     | •                                     | •     | •                                     |
|                       | Low voltage   | •                                     | •                                     | •     | •                                     |
| S                     | Short-circuit   | •                                     | •                                     |       | •                                     |
| otio                  | Asymmetry between phases  | •                                     | •                                     | •     | •                                     |
| ī                     |   | •                                     | •                                     | •     | •                                     |
| E<br>F                | Incorrect phase sequence  | •                                     | •                                     |       | •                                     |
| nati                  | Inverse power   | •                                     | •                                     |       | •                                     |
| Alter                 | Overload Canast size of drag  | •                                     | •                                     | •     | •                                     |
|                       | Genset signal drop  Total hour counter  | •                                     | •                                     | •     | •                                     |
|                       | Partial hour counter  | •                                     | •                                     | •     | •                                     |
|                       | Kilowatt meter  | •                                     | •                                     | •     | •                                     |
|                       |   | •                                     | •                                     | •     | •                                     |
| ters                  | Starts valid counters   |                                       |                                       |       |                                       |
| 0<br>U                | Starts failure counters   | •                                     | •                                     | •     | •                                     |
|                       | Maintenance<br>RS232  | •                                     | •                                     | •     | •                                     |
|                       |   | 0                                     | 0                                     | 0     | 0                                     |
|                       | RS485   | 0                                     | 0                                     | 0     | 0                                     |
|                       | Modbus IP   | 0                                     | 0                                     | 0     | 0                                     |
|                       | Modbus  | 0                                     | 0                                     | 0     | 0                                     |
|                       | CCLAN   | 0                                     | 0                                     |       | 0                                     |
|                       | Software for PC   | 0                                     | 0                                     | 0     | 0                                     |
| Sug                   | Analogue modem  | 0                                     | 0                                     | 0     | 0                                     |
| cati                  | GSM/GPRS modem  | 0                                     | 0                                     | 0     | 0                                     |
| Ē                     | Remote screen   | 0                                     | 0                                     |       | 0                                     |
| Com                   | Tele signal   | <b>()</b> (8 + 4)                     | ① (8 + 4)                             |       | (0) (8 + 4)                           |
|                       | J1939   | (100)                                 | (100)                                 | (100) | (100)                                 |
|                       | Alarm history   |                                       |                                       |       |                                       |
|                       |   |                                       | •                                     | •     |                                       |
|                       | External start  | •                                     |                                       |       | •                                     |
|                       | Start inhibition  | •                                     | •                                     | •     | •                                     |
|                       | Start inhibition  Mains failure start   | <del></del>                           |                                       |       |                                       |
|                       | Start inhibition  Mains failure start  Start under normative EJP  | •                                     | •                                     | •     | •                                     |
|                       | Start inhibition  Mains failure start  Start under normative EJP  Pre-heating engine control  | •                                     | •                                     | •     | •                                     |
|                       | Start inhibition  Mains failure start  Start under normative EJP  Pre-heating engine control  Genset contactor activation   | •                                     | •                                     | •     | •                                     |
|                       | Start inhibition  Mains failure start  Start under normative EJP  Pre-heating engine control  Genset contactor activation  Mains & Genset contactor activation  | •                                     | •                                     | •     | •                                     |
|                       | Start inhibition  Mains failure start  Start under normative EJP  Pre-heating engine control  Genset contactor activation  Mains & Genset contactor activation  Fuel transfer control   | •                                     | •                                     | •     | •                                     |
|                       | Start inhibition  Mains failure start  Start under normative EJP  Pre-heating engine control  Genset contactor activation  Mains & Genset contactor activation  Fuel transfer control  Engine temperature control   | •                                     | •                                     | •     | •                                     |
|                       | Start inhibition  Mains failure start  Start under normative EJP  Pre-heating engine control  Genset contactor activation  Mains & Genset contactor activation  Fuel transfer control  Engine temperature control  Manual override  | •                                     | •                                     | •     | •                                     |
|                       | Start inhibition  Mains failure start  Start under normative EJP  Pre-heating engine control  Genset contactor activation  Mains & Genset contactor activation  Fuel transfer control  Engine temperature control  Manual override  Programmable alarms   | •                                     | •                                     | •     | • • • • • • • • • • • • • • • •       |
| 894                   | Start inhibition  Mains failure start  Start under normative EJP  Pre-heating engine control  Genset contactor activation  Mains & Genset contactor activation  Fuel transfer control  Engine temperature control  Manual override  Programmable alarms  Genset start function in test mode   | •                                     | •                                     | •     | • • • • • • • • • • • • • • • • •     |
| satures               | Start inhibition  Mains failure start  Start under normative EJP  Pre-heating engine control  Genset contactor activation  Mains & Genset contactor activation  Fuel transfer control  Engine temperature control  Manual override  Programmable alarms  Genset start function in test mode  Programmable outputs   | •                                     | •                                     | •     | • • • • • • • • • • • • • • • • • • • |
| Features              | Start inhibition  Mains failure start  Start under normative EJP  Pre-heating engine control  Genset contactor activation  Mains & Genset contactor activation  Fuel transfer control  Engine temperature control  Manual override  Programmable alarms  Genset start function in test mode  Programmable outputs  Multilingual   | •                                     | • • • • • • • • • • • • • • • • •     | •     | • • • • • • • • • • • • • • • • • • • |
| Features              | Start inhibition  Mains failure start  Start under normative EJP  Pre-heating engine control  Genset contactor activation  Mains & Genset contactor activation  Fuel transfer control  Engine temperature control  Manual override  Programmable alarms  Genset start function in test mode  Programmable outputs  Multilingual  GPS Positioning  | • • • • • • • • • • • • • • • • • • • | • • • • • • • • • • • • • • • • • • • | •     | • • • • • • • • • • • • • • • • • • • |
| ions Features         | Start inhibition  Mains failure start  Start under normative EJP  Pre-heating engine control  Genset contactor activation  Mains & Genset contactor activation  Fuel transfer control  Engine temperature control  Manual override  Programmable alarms  Genset start function in test mode  Programmable outputs  Multilingual  GPS Positioning  Synchronisation   | • • • • • • • • • • • • • • • • • • • | • • • • • • • • • • • • • • • • • • • | •     | • • • • • • • • • • • • • • • • • • • |
| notions Features      | Start inhibition  Mains failure start  Start under normative EJP  Pre-heating engine control  Genset contactor activation  Mains & Genset contactor activation  Fuel transfer control  Engine temperature control  Manual override  Programmable alarms  Genset start function in test mode  Programmable outputs  Multilingual  GPS Positioning  Synchronisation  Mains synchronization                          | • • • • • • • • • • • • • • • • • • • |                                       | •     |                                       |
| el Functions Features | Start inhibition  Mains failure start  Start under normative EJP  Pre-heating engine control  Genset contactor activation  Mains & Genset contactor activation  Fuel transfer control  Engine temperature control  Manual override  Programmable alarms  Genset start function in test mode  Programmable outputs  Multilingual  GPS Positioning  Synchronisation  Mains synchronization  Second Zero elimination | • • • • • • • • • • • • • • • • • • • |                                       | •     | • • • • • • • • • • • • • • • • • • • |
| unctions              | Start inhibition  Mains failure start  Start under normative EJP  Pre-heating engine control  Genset contactor activation  Mains & Genset contactor activation  Fuel transfer control  Engine temperature control  Manual override  Programmable alarms  Genset start function in test mode  Programmable outputs  Multilingual  GPS Positioning  Synchronisation  Mains synchronization                          | • • • • • • • • • • • • • • • • • • • |                                       | •     |                                       |

Standard

Optional









## CONTROL PANELS



#### **M5**

Digital manual Auto-Start control panel and thermal magnetic protection (depending on current and voltage) and differential with CEM7.

Digital control unit CEM7



#### AS5

Automatic panel WITHOUT transfer switch and WITHOUT mains control with CEM7 unit. (\*) AS5 as optional with CEA7 unit. Automatic panel without transfer switch and WITH mains control.






#### CC2

Himoinsa Switching cabinet WITH display

Digital control unit CEC7



#### AS5 + CC2

Automatic panel WITH transfer switch and with mains control. The display will be on the genset and on the cabinet.

Digital control unit CEM7+CEC7



#### AC5

Automatic mains failure control panel. Wall-mounted cabinet WITH transfer switch and thermal magnetic protection (depending on current and voltage).

Digital control unit CEA7



#### Electric control and power panel with measurements devices and control unit (according to necessity and configuration)

- Battery Switch
- Adjustable earth leakage protection (time & sensitivity) standard in M5 and AS5, with thermal magnetic protection
- Battery charger (standard on gensets with automatic control panels)
- Heating resistor (standard on sets with automatic control panels)
- Battery charger alternator with ground connection

### Electrical system

- Starter battery/ies installed (cables and bracket included)
- Ground connection electrical installation with connection ready for ground spike (not supplied)



