



Guidelines for fitting Fabricated Curves

Fabricated stair nosings are made from a template that has made on the step

The fabrication will have been made oversized at both ends. This is necessary for the customer to fit exactly to the step. On the underside of the nosing a cutting guide mark will have been placed at each end.

When fitting, the following guidelines should be adhered to -:

1. Create a new template to exact ends. Take care to draw the shape needed at each end of the template.
2. Place the template against the fabricated curve and match up.
3. Carefully draw cutting lines on the underside of the metal.
4. Cut the metal at the lines. If possible try the curve against the step at each stage
5. Once the correct shape has been cut, fix the metal to the step using the correct screws.

Further details can be obtained from Morleys 2013 Ltd.
Email – sales@morleys2013.co.uk