

Phraseology Examples

In the examples given, the critical parts are designated as follows:

UPPERCASE Indicates words that are to be spoken exactly as written

(in parentheses) Describes the information to be inserted

/ slash Indicates that there are alternative words or information; use only one

Example:

Reads as: SPEAK LOUDLY AT/IN (unit name)

Spoken as: Speak loudly at home ...or... Speak loudly in the hangar

Phonetic Alphabet

Alphabet	Pronunciation	Alphabet	Pronunciation
A – Alfa	AL fah	N – November	No VEM ber
B – Bravo	BRAH VOH	O – Oscar	OSS cah
C – Charlie	CHAR lee	P – Papa	Pah PAH
D – Delta	DELL tah	Q – Quebec	Keh BECK
E – Echo	ECK oh	R – Romeo	ROW me oh
F – Foxtrot	FOKS trot	S – Sierra	See AIR ah
G – Golf	GOLF	T – Tango	TANG go
H – Hotel	Hoh TELL	U – Uniform	YOU nee form
I – India	IN dee ah	V – Victor	VIK tah
J – Juliett	JEW lee ETT	W – Whiskey	WISS key
K – Kilo	KEY loh	X – X-Ray	ECKS Ray
L – Lima	LEE mah	Y – Yankee	YANG key
M – Mike	MIKE	Z – Zulu	ZOO loo

Numbers

Term	Pronunciation	Term	Pronunciation
0	ZE RO	7	SEV en
1	WUN	8	AIT
2	TOO	9	NIN er
3	TREE	Decimal	DAY SEE MAL
4	FOW er	Hundred	HUN dred
5	FIFE	Thousand	TOU SAND
6	SIKS		

Number	Pronunciation
10	ONE ZERO
74	SEVEN FOUR
100	ONE ZERO ZERO
584	FIVE EIGHT FOUR
12000	ONE TWO THOUSAND or ONE TWO ZERO ZERO ZERO
38542	THREE EIGHT FIVE FOUR TWO

 ATS at times use **NINER** and **FIFE** (particularly when communicating with aircraft). However ground vehicle operators and aircraft maintenance engineers are not required to use these terms and may use **NINE** and **FIVE**.

Roman Numerals

Number	Roman Numeral	Number	Roman Numeral
1	I	11	XI
2	II	12	XII
3	III	13	XIII
4	IV	14	XIV
5	V	15	XV
6	VI	16	XVI
7	VII	17	XVII
8	VIII	18	XVIII
9	IX	19	XIX
10	X	20	XX

Some airports use Roman numerals to distinguish apron locations and instrument landing system (ILS) category hold lines.

Examples:



 DRIVER	Regina Ground, this is Staff two-three located at Apron I
 ATC	Staff two-three, Regina Ground, state your request/what are your intentions?

Standard Words and Phrases

Word	Meaning
ACKNOWLEDGE	Let me know you have received and understood this message.
AFFIRMATIVE	Yes.
APPROVED	Permission granted.
BREAK	Separation between portions of the message.
BREAK BREAK	Separation between messages for two different aircraft.
CHECK	Examine a system or procedure.
CONFIRM	Verify (clearance, instruction, action, information) given.
CONTACT	Establish communication with...
CORRECT	True or accurate.
CORRECTION	An error was made in transmission, the correction will follow.
DISREGARD	Ignore.
EXPEDITE	Comply with instruction as soon as possible.
HOW DO YOU READ?	Can you hear my transmission clearly?
I DO NOT UNDERSTAND	I do not understand, please rephrase your last transmission.
I SAY AGAIN	I repeat for clarity or emphasis.
IMMEDIATELY	Immediate action as required for safety reasons.
MONITOR	Listen to (frequency) without checking in.
NEGATIVE	No, or Permission not granted, or Not correct, or Not capable.
OVER	End of transmission, require response.
READ BACK	Repeat all, or specified part of message back.
RECLEARED	A change has been made to your last clearance and this new clearance supersedes your previous clearance or part thereof.
ROGER	I have received your transmission (generally used by ATC rather than pilots).
SAY AGAIN	Repeat all, or specified part of last transmission.
SPEAK SLOWER	Reduce rate of speech.
STAND BY	Wait and monitor frequency, caller will re-establish contact.
UNABLE	Cannot comply with instruction, or clearance, or request.
WILCO	I understand the message and will comply.
WITHOUT DELAY	Follow instructions expeditiously, specifically and safely.
WORDS TWICE	Communication difficult: please say every word or group of words twice. Communication difficult: therefore, I will repeat every word/group of words twice.




You may hear phraseology such as "blocked," "stepped on," or "two at once" used by ATS or other pilots. These phrases all indicate that your transmission was interrupted or distorted by other radio transmissions.


Air Traffic Service (ATS) Units

ATS units also have a designated call sign and associated frequency. This call sign is comprised of geographic location, followed by the type of service provided.

ATS Unit	Function	Call Sign	
Airport Control	Clearance Delivery	(unit name) CLEARANCE DELIVERY	
	Ground Control	(unit name) GROUND	
	Tower Control	(unit name) TOWER	
Terminal Control	Arrival Control	(unit name) ARRIVAL	
	Departure Control	(unit name) DEPARTURE	
	Terminal Control	(unit name) TERMINAL	
Area Control		(unit name) CENTRE	
Flight Service Station (FSS)	Aerodrome Advisory Service (AAS)	(unit name) RADIO	
Flight Information Centre (FIC)	Flight Information Service Enroute-FISE (FIC)	(unit name) RADIO	
Community Airport Radio Station (CARS)	WX Service, Information	(unit name) AIRPORT RADIO	
Example:	Ottawa Clearance Delivery Norman Wells Radio	Montreal Arrival Cambridge Bay Airport Radio Edmonton Radio	Vancouver Ground



General Format of Radio Communication



Staff three-three, Ground, hold short of runway two-three.



Ground, Staff three-three, roger, hold short of runway two-three.

Initial Contact

On initial contact, inform ATS of who you are (using your full call sign) and where you are. This gives them a better idea as how to proceed with your request. Next, identify the destination you want to go to and your intentions once you get there. Be sure you are not requesting a specific route unless it is necessary; ATS will provide a route for you.

Driver: (Operating position/function) (vehicle ident) LOCATED AT (location ident).

ATS: (vehicle ident) (Operating position/function) STATE YOUR REQUEST/WHAT ARE YOUR INTENTIONS?

 DRIVER	Ground, Staff two-eight is on Juliet
 ATC	Staff two-eight, Ground, what are your intentions?
 DRIVER	Staff two-eight request permission to go on Alfa to check the lights.
 ATC	Staff two-eight, Ground. Proceed on Alfa, hold short runway zero-five.
 DRIVER	Ground, Staff two-eight will hold short runway zero-five on Alfa.



Stand By

"Stand by" is generally used when there is time needed between transmissions. This may be to verify or gather information, or because there is another task being performed. "Stand by" means wait, the individual that initiated the stand by will re-establish contact when they are ready to do so.

Driver: (Operating position/function) (vehicle ident).

ATS: (vehicle ident) (unit identification) STAND BY.

ATS: (vehicle ident) (unit identification) STATE YOUR REQUEST/WHAT IS YOUR REQUEST.

 DRIVER	Ottawa Ground, Tractor one-five-zero at Esso.
 ATC	Tractor one-five-zero, Ground, stand by.
 ATC	Tractor one-five-zero, Ground, say your request.



If the frequency is busy, ATS will ensure the highest priority calls are made first. If you have contacted ATS and they do not respond immediately, wait; they may be attending to a higher-priority task. ATS personnel may be doing other tasks that do not require the use of the frequency, but are equally important. Radio silence does not mean that ATS personnel are not occupied.

Radio Check

Readability	Description
1	Unreadable
2	Readable now and then
3	Readable but with difficulty
4	Readable
5	Perfectly readable

ATS may ask you to verify the readability of their radio transmission. Conversely, you may ask ATS to verify the readability of your radio transmissions.

Driver: (Operating position/function) (vehicle ident) RADIO CHECK/HOW DO YOU READ?

ATS: (vehicle ident) (unit identification) READ YOU (readability number).

 DRIVER	Ottawa Ground, Truck one-one-three, how do you read?
 ATC	Truck one-one-three, Ottawa Ground, read you three, background static.
 DRIVER	Truck one-one-three.

Report Your Position

ATS may ask you to report your position. Be sure to be as precise as possible in your response. Use runway numbers, taxiway letters, etc.

ATS: (vehicle ident) REPORT/SAY/STATE YOUR POSITION.

Driver: (vehicle ident) (location ident).

 ATC	Maintenance two-four-seven, report your position.
 DRIVER	Ground, Maintenance two-four-seven at apron one.

Proceed Via

Every route that is given to you is specified following the words "proceed via." Note that the route you are given may not be exactly as you anticipate.

 DRIVER	Calgary Ground, Truck eight-one, off runway one-one request to proceed to the apron (driver is anticipating instructions via Charlie, Juliett, Juliett-Romeo which is often the normal route).
 ATC	Truck eight-one, roger proceed via Charlie, Juliett, Juliett-Tango to the apron.
 DRIVER	Truck eight-one, proceed Charlie, Juliett, Juliett-Tango to the apron.



Be mindful that ATS may have to redirect you on a different route than usual due to different factors including: traffic, construction, obstacles, etc. Listen carefully so you don't over-anticipate the instructions.

Give Way To

“Give way to” requires you to yield right of way to specified aircraft or vehicles. Once given this instruction, scan the area to locate the vehicle or aircraft stated by ATS.

ATS: (vehicle ident) PROCEED VIA (runway, taxiway, location) GIVE WAY TO (description and position of aircraft/vehicle).

 DRIVER	Toronto ground, Truck eight-one on Juliett, request to proceed to main apron.
 ATC	Truck eight-one proceed via Alfa give way to the Boeing seven-three-seven on Alfa at Tango.

Hold Position

While on the airfield you may be instructed to “hold position.” When you are given this instruction, you must remain where you are until given further details.

FSS: (vehicle ident) HOLD POSITION.

 ATC	Staff two-seven, hold position.
 DRIVER	Staff two-seven, roger, holding position.

Hold Short

When instructed to “hold short,” you do not have permission to enter the runway; you must stay behind the hold short line until further advised. Being told to hold short of taxiways or other specific locations on the airfield is also a frequent occurrence. It should also be noted that you do not have permission to enter a runway unless you are given permission onto that runway. Vehicles should question an instruction that does not have a hold short or permission onto a runway if the route takes them to a runway.

ATS: (vehicle ident) HOLD SHORT (runway, taxiway, location).

 DRIVER	Thompson Radio, Sweeper one-five-one, at the south apron, request to go to the north apron via Alfa Charlie.
 FSS	Sweeper one-five-one, Thompson Radio, negative, proceed via Alfa, hold short runway zero-six.
 DRIVER	Thompson Radio, Sweeper one-five-one, proceeding via Alfa, hold short runway zero-six.

Hold Short and Read Back

When you are told to "hold short," you are required to read back the instruction. When this occurs, read back the complete instruction given.

FSS: (vehicle ident) HOLD SHORT (runway, taxiway ident).

Driver: (vehicle ident) ROGER, HOLD SHORT (runway/taxiway ident).

 FSS	Staff two-two proceed onto taxiway Alfa, hold short runway two-four.
 DRIVER	Staff two-two, Roger, proceed onto taxiway Alfa, hold short runway two-four.



An instruction to HOLD SHORT of a runway must be read back.



Your speed should change according to weather conditions, as it could be slippery at hold short lines.



To ensure ATS knows you are able to stop when weather conditions are poor, you should visibly slow down before reaching hold short line.

Crossing a Runway

If you need to cross a runway, you must get specific permission and instructions from ATS first. ATS will give you the instruction to either "cross" or "hold short" of each runway.

ATS: (vehicle ident) CROSS RUNWAY (runway number).

	Blower one-two-two, cross runway zero-six right.
	Blower one-two-two, crossing runway zero-six right.

	Red one, proceed via Echo, cross runway two-eight to de-icing facility.
	Red one, proceeding via Echo, crossing runway two-eight to de-icing facility.

 **Before crossing a runway, you must be given clearance from ATS.**

 **When instructed to cross a runway, make sure you go past the hold short line on the opposite side of the runway.**


 **Only cross a runway when it is absolutely necessary. Use perimeter roads when possible.**

Report Off

You may be required to notify ATS when you are no longer on a runway or taxiway. ATS may instruct you to either "report off" or "advise off." When off of the runway, contact ATS and advise that you have vacated the runway.

ATS: (vehicle ident) ADVISE OFF/REPORT OFF (runway, taxiway, location).

	Maintenance two-four-zero, advise off runway zero-seven.
	Maintenance two-four-zero, roger.
	Maintenance two-four-zero, off runway zero-seven.



Do not report off until you are across the hold short line of a runway.

Say Again

If you do not hear or understand a transmission from ATS, reply with "say again" and ATS will repeat the transmission.

ATS: (vehicle ident) (instruction).

Driver: (vehicle ident) SAY AGAIN.

ATS: (vehicle ident) (instruction).

 ATC	Truck eight-two, proceed via Alfa and Hotel hold short runway two-three.
 DRIVER	Ground, Truck eight-two, say again.
 ATC	Truck eight-two, proceed via Alfa and Hotel hold short runway two-three.
 DRIVER	Truck eighty-two, roger, proceed via Alfa and Hotel hold short runway two-three.



If you are unsure of the route you have been given, ask ATS for further clarification.

Unsure of Position

If you are unsure of your position, make sure you are clear of any runway and other traffic. Stop and inform ATS, requesting progressive taxi if necessary. They will give you further direction or call for assistance.

Driver: (unit identification) (vehicle ident) UNSURE OF POSITION.

ATS: (vehicle ident) (instructions).

 DRIVER	Saskatoon Ground, Truck eight-two, unsure of position.
 ATS	Truck eight-two, roger, hold your position.
	When driving, have a map available for use.
	Always know where you are on the airfield. Be as precise as possible.

Progressive Instructions

If you are unsure of the airfield and need assistance in manoeuvering from one point to another, you can ask ATS for "progressive instructions." You will be given step-by-step directions to where you need to go.

Driver: (unit identification) (vehicle ident) (unit name).

 DRIVER	Thunder Bay Ground, this is Shell three-five-three, on Foxtrot.
 ATC	Shell three-five-three, Ground.
 DRIVER	Shell three-five-three, request progressive clearance to main apron.
 ATC	Shell three-five-three, proceed via runway one-two, hold short runway zero-seven.
 DRIVER	Shell three-five-three, proceed via runway one-two, hold short runway zero-seven.
 DRIVER	Shell three-five-three holding short runway zero-seven.

 ATC	Shell three-five-three, cross runway zero-seven, proceed Alfa to main apron.
 DRIVER	Shell three-five-three, cross runway zero-seven, proceed Alfa to main apron.
 DRIVER	Shell three-five-three, reporting off runway zero-seven.


Operating on a Runway

ATS cannot give instructions that allow for unrestricted ground movement on the manoeuvering area. ATS cannot authorize you to: "proceed on the field," "proceed unrestricted," or "proceed on all manoeuvering areas." Clearances onto runways must specify the runway number.

 DRIVER	Saskatoon radio, Staff two-three on taxiway Charlie, request to proceed onto runway zero-nine.
 FSS	Staff two-three proceed onto runway zero-nine, cross runway one-five until further advised.



When operating on a runway, keep your eyes and ears open; people can make mistakes.



Without Delay

You may be asked by ATS to increase your speed while on the airfield. This must be done with caution and within reason. The phrases "without delay" or "expedite" are used for this instruction.

ATS: EXIT/PROCEED/CROSS (runway, taxiway) WITHOUT DELAY

 ATS	Staff two-seven, cross runway one-four without delay and report off.
 DRIVER	Staff two-seven crossing runway one-four without delay and will report off.



If unable to comply with the promptness of the instruction do not proceed and advise ATS immediately unless the instruction is to vacate a runway!

Negative

ATS may at times refuse or delay your request. ATS will inform you as to why and, if they are able, they will give you an alternative option or further instructions.

Driver: (unit identification) (vehicle ident) (request).

ATS: NEGATIVE, (instruction) HOLD SHORT/HOLD YOUR POSITION (reason).

 DRIVER	Kelowna Ground, Sweeper one-seven-three, request to cross runway one-six.
 ATC	Sweeper one-seven-three, Ground, negative, hold short runway one-six, landing traffic.
 DRIVER	Sweeper one-seven-three, hold short runway one-six.

 DRIVER	Kelowna Ground, Sweeper one-seven-three, request to proceed onto taxiway Delta.
 ATC	Sweeper one-seven-three, negative, hold short Delta, opposite direction traffic.
 DRIVER	Sweeper one-seven-three, hold short Delta.

Leave/Exit

When instructed to vacate a runway or taxiway, ATS provides you with information, direction, and a reason, if necessary. You may be required to report off.

ATS: LEAVE/EXIT/VACATE/GET OFF (runway id, taxiway id) AT (unit name) REPORT OFF

	Mower two-two-six, exit the runway protected area, aircraft landing runway one-one, report off.
	Mower two-two-six, roger, exit the runway protected area and report off.
	Truck eight-zero, exit runway three-four at Juliett, report off.
	Truck eight-zero, roger, exit runway three-four at Juliett and will report off.
	Blower one-two-one, leave taxiway Juliett at Hotel and report off.
	Blower one-two-one, roger, exit Juliett at Hotel and report off.

“Did You Know” – Runway Incursions

Definition: Runway Incursion includes any occurrence at an aerodrome involving the incorrect presence of an aircraft, vehicle, or person on the protected area of a surface designated for landing and take-off of aircraft.



The Transportation Safety Board (TSB) put runway incursions on its watch list.

As part of the Safety Management System (SMS), NAV CANADA is proactively managing risk associated with runway incursions. Best practices play an important role in this process.

Runway Protected Area

Runway Protected Area (RPA) is the 200-foot area (unless otherwise designated) from the edge of a runway established to protect aircraft that are taking off and landing from taxiing aircraft as well as ground traffic. The RPA is usually depicted by a line, however not always (e.g. grassy areas). Before requesting to go into the RPA, you must first give ATS the following information: identification, present position, and your intentions. ATS either approves your request, or instructs you to remain outside of the RPA. The phrase "RPA" or "runway protected area" may not be used in the actual clearance, but an area inside the RPA may be referenced (see examples below).

Driver: (unit identification)(vehicle ident)(unit name)(request).

 DRIVER	Windsor Ground, Truck eight-one, on taxiway Foxtrot request to work on Foxtrot at the edge of runway three-zero.
 ATC	Truck eight-one, roger, proceed Foxtrot and onto runway three-zero.

 DRIVER	Windsor Ground, Mower two-two-five, request to cut grass along runway two-five.
 ATC	Mower two-two-five, negative, traffic departing.

Instrument Landing System Critical Area

The Instrument Landing System (ILS) Critical area is identified by "Restricted Area" signs. This area must be clear of vehicles prior to an aircraft landing. This is intended to ensure the integrity of the ILS antenna signal and reduce the possibility of interference. You must obtain specific instructions to enter this area.

 ATC	Tech five-four, proceed to the ILS shack, report leaving the restricted area.
 ATC	Tech five-four, negative, traffic landing.
 ATC	Tech five-four, negative, hold short ILS critical area due to aircraft on approach.
 ATS	Staff two-seven, leave the restricted area, traffic landing, report off.



Truck eight-one, negative, hold short ILS critical area due to aircraft on approach.



Truck eight-one, holding short ILS critical area.



Truck eight-one, leave the restricted area, aircraft on approach, report off.



Truck eight-one, roger, off the restricted area.



Repetitive Operations

During times of repetitive ground traffic operations, ATS may instruct you to operate on a single runway and through a runway intersection. Multiple vehicles may be authorized to operate on different runways, but each vehicle is limited to a single runway at a time.

ATS: PROCEED onto (runway ident), CROSS (runway ident) UNTIL FURTHER ADVISED.

 **Blower one-two-zero proceed onto runway two-four cross runway three-six until further advised.**

Multiple Vehicles

The lead vehicle in a group of vehicles is the one contacting ATS. They must inform the ATS of the number of vehicles ("plus three"), the operation/task being performed, and the speed and duration of movement on the airfield. The vehicle leading the group is the only one who is in contact with ATS. They inform ATS when a vehicle needs to leave the group, join the group etc. If the lead vehicle needs to leave, it is their job to identify a new vehicle contact – this new contact should establish communication with ATS.

 DRIVER	Winnipeg Ground, this is Blower one-two-eight plus three.
 ATC	Blower one-two-eight plus three, Winnipeg Ground.
 DRIVER	Ground, Blower one-two-eight plus three request to plow runway three-one full length.
 ATC	Blower one-two-eight plus three, proceed onto runway three-one, cross runway three-six until further advised.
 DRIVER	Ground, Blower one-two-eight is requesting to proceed to the main apron, Blower one-two-two now lead vehicle.
 ATC	Blower one-two-eight, roger, exit runway three-one at Victor to the apron.
 ATC	Blower one-two-two plus two, you are now the contact vehicle on runway three-one.



Have a briefing for all drivers before moving onto the airfield. Set up communications between all drivers, have a plan before starting, and set up a response route for vehicles that might join the group.



Broken Down Vehicle

If your vehicle breaks down, inform ATS of your exact location immediately. They will send another vehicle to assist.

Driver: (unit identification) (vehicle ident) BROKEN DOWN (unit name).



Fort McMurray Ground, Staff two-seven, broken down, taxiway Delta north side of runway zero-seven.



Best Practice – Be aware that some vehicles operating at uncontrolled aerodromes may not be equipped with a radio, in particular vehicles requiring an escort.

Towing an Aircraft

Before towing an aircraft on the field or on the manoeuvring area, you must first contact ATS for instruction. You must also inform them of the aircraft type (primarily at smaller airports).

Driver: (unit identification) (vehicle ident) REQUEST TOW (unit name).

 DRIVER	Regina Ground, Tug two-two-nine request tow Boeing seven-thirty-seven from maintenance hangar three to gate two-five.
 ATC	Tug two-two-nine, Regina Ground, proceed via Charlie to gate two-five.
 DRIVER	Tug two-two-nine, roger proceed via Charlie.



Recommended Practice – Always state aircraft type when towing an aircraft.



Low Visibility/Night

There is often a greater chance of runway and taxiway incursions taking place during low visibility and at night. Be prepared and be familiar with the airfield and phraseology to ensure safety for everyone.


Focusing more on the signage instead of bright lights helps you to navigate through the airfield more effectively.



Workers do not usually use interior vehicle lights at night to ensure reflections from inside the car do not affect their driving vision.



Be aware of your surroundings and stay clear of hot spots, especially at night and in low visibility. Be mindful that it is very possible that ATS personnel may have difficulty seeing you during these times.



Wildlife

It is common for ground vehicle operators to spot wildlife on the airfield. It is important to report these sightings as soon as possible to ATS or to airside operations. Birds or animals can be a hazard to aircraft, causing major damage or potential accidents.

 DRIVER	Timmins Radio, staff two-one.
 FSS	Staff two-one, Timmins Radio.
 DRIVER	Staff two-one, we've had a report of a coyote at the threshold of runway zero-three, request to proceed via Bravo to the threshold of runway zero-three.
 FSS	Staff two-one, proceed via Bravo onto runway zero-three, hold short runway two-eight.
 DRIVER	Staff two-one, roger, proceeding Bravo onto runway zero-three, hold short runway two-eight.

Foreign Object Debris (FOD)

FOD is a substance, debris, or article alien to a vehicle or system which could potentially cause damage. Ingesting FOD into a jet engine or a propeller hit can cause significant damage and pose a major safety risk.



Foreign object debris (FOD) at airports can cause damage that costs airlines, airports, and airport tenants millions of dollars every year.




If you see it, pick it up.

 FSS	Staff two-two, Lethbridge Radio.
 DRIVER	Lethbridge Radio, Staff two-two.

 FSS	Staff two-two, FOD reported at the intersection of Bravo and runway one-two.
 DRIVER	Staff two-two Roger, at the main apron request to proceed via bravo onto runway one-two.
 FSS	Staff two-two, proceed via Bravo onto runway one-two, hold short runway two-three.
 DRIVER	Staff two-two Roger, proceed via Bravo to runway one-two, hold short runway two-three.

Aircraft Rescue and Fire Fighting

When an emergency situation takes place on the airfield, ATS gives emergency crews specific instructions and routing in order to address it in the safest manner possible. During emergency situations, ground vehicles responding must always ensure communication with ATS. ATS provides emergency crews with specific instructions and follows emergency procedures established by both parties. As a rule, Aircraft Rescue and Fire Fighting (ARFF) have priority over other vehicles.



Communication Failure/Flashing of Runway Lights

If you lose radio communications, at an airport with a control tower, position your vehicle facing the tower and stop. Control towers will use light signals (commonly known as a light gun) to issue further instructions. The lights control aircraft and the movement of vehicles, equipment, and personnel on the manoeuvring area when radio communications cannot be employed. Not included in the chart below are flashing runway edge lights; if all other communication fails, you may flash the **runway lights** on and off as a signal to vehicles and pedestrians to vacate the active runway.

Steady green		NA
Flashing green		Cleared to cross; proceed; go.
Steady red		Hold your position; stop.
Flashing red		Vacate the runway immediately
Flashing white		Return to starting point on aerodrome

